

注: L2为印刷电路板的印制导线(发射天线)。 A键 B键为遥控发射键,按下时遥控器发射信号,可控制接收电路使绞盘机正转或反转。

Notes:

1. L2 is the transmitting antenna.

2. Button A and B will transmit the signals to control winch forward and reverse.