Test setup of low frequency



Field Strength Emissions Test Set-up - Lying mode




Field Strength Emissions Test Set-up - Side mode



Field Strength Emissions Test Set-up - Stand mode

Test setup of High frequency



Field Strength Emissions Test Set-up