RSF720. PCB			
Part	Used	PartType	Designators
1		1k	R21 R25 R30 R34
2		1k2	R1
3		1p	C24
4		2k2	R2 R18
5		2u2	E1 E2 E8
6		3. 3uH	L1 L2 L3
7 8		3T5	L5 L6 L7
9		3k3 4T5	R10 L4
10		415 4u7	E3 E4 E6 E9
11		5k6	R5 R16 R27
12		9V	BATT
13	1		R29
14		10k	R7 R11 R13 R17 R20 R24 R33
15		10 k	C21 C26
16		10p 18k	R32
17		20MHz	XAL
18		20P	VC1 VC2 VC3 C2 C5
19		22k	R3 R4 R6 R14
20		22p	C17
21		30p	C11 C13 C25
22		33k	R8 R9 R19 R23
23		42p	C12
24	1		T02
25	1		T03
26	1		R12
27		47k	R15
28		47u	E5
29		50p	C6 C10 C18
30		68p	C14
31		78L05	IC2
32			E7
33	1	101	
34	10	102	C4 C7 C19 C20 C22 C23 C27 C30 C31 C32
35	6		C3 C9 C15 C16 C28 C29
36	2	104	C8 VR1
37	1	150k	R31
38	1		R28
39	1	618	
40	2		R22 R26
41	1	2638	
42	1	4558	
43		C1815	Q5 Q6
44		C1906	Q1 Q2 Q3 Q4
45		K2X4	SW1
46		LED	D2
47		MIC	MIC
	103		
S_1	200 and 1	(5 <u>0</u> -76-5)-2-3	- A-17
frequency	C13	C17	C12
174.1MHz-215.6 MHz	3 0p	22p	42p
3 5			