
Photograph 17&18: Top View Rx'er PCB



Underside view Rx'er PCB




Photograph 19&20: Top View Controller PCB




Underside view Controller PCB




Photograph 5&6: Top View Main Audio PC




Underside view Main Audio PC




Photograph 7&8: Top View SBC Support PCB




Underside view SBC Support PCB



Photograph 9&10: Top View Aux PCB




Underside view Aux PCB



Photograph 11&12: Top View SBC




Underside view SBC



Photograph 13&14: Top View T36 Option PCB




Underside view T36 Option PCB




Photograph 15&16: Top View Tx'er exciter PCB




Underside view Tx'er exciter PCB



Photograph 21&22 Top View Digital I/O PCB



Underside view Digital I/O PCB



Photograph 23: Top View 100W P. A. PCB

