SM-902 Mini Wireless Optical Mouse User Manual

WELCOME

Thank you for selecting this product! Your RF Mini Wireless Optical Mouse uses a newly developed RF wireless technology 27MHz that replaces the traditional wired mouse. The receiver also can be used as a charger. So you need not worry about your battery will use out

PRODUCT FEATURES

- 1. Radio frequency 27MHz, enjoy your freely wireless space.
- 2. It has 256ID code, there is no interference even many mice being used at the same time.
- 3. Automatically sleeping and manpower taking off dual functions, the battery life be prolonged.

SYSTEMS COMPATIBILITY

IBM PC and Wind98/Me/2000/XP/NT

No need driver

THE STEPS OF INSTALLBATTERY

- 1. Please prepare for two PCS new AA chargeable batteries
- 2. Press the button of the mouse upper cover and pull the battery cover rearward
- 3. Please insert the batteries correctly according to the polarity marks of the battery grooves
- 4. Pull the battery covers forward, when you hear crack sound which shows the battery cover is locked successfully

RECEIVER INSTALLATION

- 1. If you use ps/2 connector, please use the USB to PS/2 adaptor and connect with the connector before your computer star-up
- 2. For laptop, you may connect the receiver directly
- 3. If you use desk PC, suggest you to put the receiver on your working surface



Press the button to open the upper cover

ID SETUP

- 1. Please mover the mouse near to the receiver
- 2. Press the ID button of the receiver by your hand. The receiver light RCV begin to flash
- 3. Press the ID button of the mouse bottom with some hard and actuate object within 10 seconds, The receiver light will flash very fast, a few seconds later it will be on which shows it is successfully for connect you may start to use it
- 4. Working distance: within 1-2 meters



Then press the button of the mouse

CHARGE THE CHARGEABLE BATTERIES

- 1. Please open the cover of the 2 in 1 receiver
- 2. Please put 2PCS batteries in to the charger and pay attention to the polarity

- 3. The indication CHG is red while charging and LED will become green if finishing charge. There is no any indication if batteries in wrong place or broken.
- 4. This charger uses USB or PS/2/25V power and uses slow charge means because in these way the battery life can be prolonged. The charge time is approx; 10 hours
- 5. This charger has auto-stop charging function and it refuses to charge the batteries which power is higher than the original design value or the battery still can be used.

ATTENTION PLEASE

- 1. Please do not make the mouse far away from the receiver in order to word more smoothly
- You could better use the mouse on the white desk. In this way the batteries can be used for a ling time
- 3. This mouse is with save power sleeping functions. Please press any key or scroll the wheel to wake up the mouse when it is sleeping
- 4. If you want to take off the mouse power immediately, please continue to press the ID, switch of the mouse button at least three seconds. If you want to take on the mouse bottom
- 5. The optical mouse will not work freely on a sooth desk, glass, any reflecting surface, 3Dmouse pad
- 6. No need to check the digital connection within 10 seconds when change the batteries, if more than that please according to the above way to re-operate

CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment

NOTE

With them limits for a class B digital device, pursuant to part 15 of the FCC rules, There limits are designed to provide residential installation. This equipment generates, uses and can radiate radio frequency energy, if not installed and used in accordance with these, instruction may cause harmful interference to radio communications. However, There is no guarantee that interference will not occur in a particular installation. if the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures; Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver connect the equipment into an outlet on a circuit different from that to which the receiver is connected Consult dealer or an experienced radio/TV technician for help. Frist press button of the receiver, then press button of the mouse Press the button to open the upper cover

This device complies with Part 15 of the FCC Rules. Operation is subject to the following Conduction: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.