List of 16 frequencies (channels) used by the Zigray Universal & pull cord transmitters.

Channel	Center freq	Tolerance	Min freq	Max Freq
(11-26)	(GHz)	(GHz)	(GHz)	
11	2.405 4.0E-05	2.4049038	2.4050962	
12	2.410 4.0E-05	2.4099036	2.4100964	
13	2.415 4.0E-05	2.4149034	2.4150966	
14	2.420 4.0E-05	2.4199032	2.4200968	
15	2.425 4.0E-05	2.4249030	2.4250970	
16	2.430 4.0E-05	2.4299028	2.4300972	
17	2.435 4.0E-05	2.4349026	2.4350974	
18	2.440 4.0E-05	2.4399024	2.4400976	
19	2.445 4.0E-05	2.4449022	2.4450978	
20	2.450 4.0E-05	2.4499020	2.4500980	
21	2.455 4.0E-05	2.4549018	2.4550982	
22	2.460 4.0E-05	2.4599016	2.4600984	
23	2.465 4.0E-05	2.4649014	2.4650986	
24	2.470 4.0E-05	2.4699012	2.4700988	
25	2.475 4.0E-05	2.4749010	2.4750990	
26	2.480 4.0E-05	2.4799008	2.4800992	