# **Weather Indicator List**

• Indicators and categories are subject to change without prior notice.

Weather		
<del>-</del>	Clear (day)	
9	Clear (night)	
ω	Cloudy	
7	Rain	
ð	Snow	
4	Thunderstorm	
0% - 100%	Precipitation 0%-100%	
$\triangleright$	Later	
	Occasionally	

Pollen Level	
4	Low
Æ	Moderate
<b>*</b>	High
	Very High

Cherry Blossom		
	Blossoms Opening	
	Near Full Bloom	
***	Peak Bloom	
ð	Past Peak	

Fall Foliage	
*	No Color
*	Moderate Color
*	Peak Color
N. C.	Past Peak

UV Level	
	Low
麥	Moderate
*	High
**	Very High

Typhoon	
<b>4</b>	Formed
	Approaching
<b>5</b>	Severe

Other Information		
<del></del>	Heavy Rain	
8	Strong Winds	
<b>₫</b>	Notifications	

# **Memory List**

Data Folder Up to 3500 items (Up to 300 MB) (One S! Appli corresponds up to 6 MB.)	

• Shared with S! Appli List

	Calendar Events	Up to 1000 items
-		'

Phone Book Up to 1000 items

Messaging	Incoming Mail	Up to 3000 items
(SMS and	Sent/Unsent	Up to 1000 items
S! Mail combined)	Drafts	Up to 10 items
	Saved Pages	[Yahoo! Keitai] Up to 20 items/750KB [PC Site Browser] Up to 20 items/1150KB
	Bookmarks	[Yahoo! Keitai] Up to 100 items [PC Site Browser] Up to 100 items
Yahoo! Keitai	URL History	[Yahoo! Keitai] URL Entry: Up to 20 items URL Access: Up to 100 items* [PC Site Browser] URL Entry: Up to 20 items URL Access: Up to 100 items*
	Cache	[Yahoo! Keitai] 750KB [PC Site Browser] 1150KB

<sup>\*</sup> The number of savable items varies depending on URL length.

# **Specifications**

940P

Weight (including battery)		149 g*
Dimensions (closed)		50 x 112 x 18.8 mm*
Standby Time	3G	640 hours*
(closed)	GSM	380 hours*
	3G	220 minutes*
Talk Time	Video Call	120 minutes*
	GSM	230 minutes*
TV Reception	Normal Mode	3.7 hours*
Time	ECO Mode	6.3 hours*
Charging Time	AC Charger	130 minutes*
Charging Time	In-Car Charger	130 minutes*
Maximum	3G	0.25 W
Output	GSM	2.0 W

- \* Approximate value
- Values above were calculated with battery installed.
- Talk Time is an average measured with a new, fully charged battery, with stable signals.
- Standby Time is an average measured with a new, fully charged battery, with handset closed without calls or operations, in Standby with stable signals.
- TV-Reception Time is an average measured using earphone/microphone, with stable signals.
- Talk Time and Standby Time may vary by environment (battery status, temperature, etc.).
- Talk Time and Standby Time may decrease when an S! Appli is active.

## Battery

Voltage	3.7 V
Battery Type	Lithium-ion
Capacity	800 mAh
Dimensions	45 x 4.5 x 37 mm*

<sup>\*</sup> Approximate value

• Specifications subject to change without notice.

**	
AC Charger	1-15
Access History	
PC Site Browser	14-5
Yahoo! Keitai	
Account Details 1-30,	4-13
Address (Adding/editing/deleting)	13-8
After-Sales Service	19-33
Alarms	
All Reset1	11-12
Alternative Image	2-6
Answer Phone	2-15
Answering Calls	
Video Calls	2-8
Voice Calls	2-5
Attachments	
Adding	13-8
Deleting	13-8
Opening/saving1	13-13
Auto Answer	
Auto Focus Lock	
Auto Save (Camera)	6-11
Auto timer	6-8
Auto-sort1	13-16
AV Output 1	10-13

A
AC Charger 1-15 Access History
PC Site Browser14-5
Yahoo! Keitai14-3
Account Details 1-30, 4-13
Address (Adding/editing/deleting) 13-8
After-Sales Service 19-33
Alarms 12-6
All Reset 11-12
Alternative Image2-6
Answer Phone 2-15
Answering Calls
Video Calls 2-8
Voice Calls 2-5
Attachments
Adding 13-8
Deleting 13-8
Opening/saving 13-13
Auto Answer 18-7
Auto Focus Lock 6-13
Auto Save (Camera)6-11
Auto timer
Auto-sort
AULU-SUIT 13-10

В	
Back Light	
Display	18-5
S! Appli	
Video Calls	2-13
Backup	
microSD Card	
S! Address Back-up	4-10
Bar Code Reader	12-11
Basic Operations	
Handset	X
Internet	
Battery	
Battery Level	
Bluetooth®	
Bluetooth® Passkey	
Bookmarks	
Books folder	
BookSurfing®	7-8
Brightness	
Back Light	
Camera	
External Display	
Video Calls	
Browser (Initializing)	18-21

	ndiv
1	9

С
Cache Memory 14-2
Calculator 12-8
Calendar 12-2
Calendar Events 12-2
Call Barring2-20
Call Cost 18-9
Call Forwarding 2-17
Call Log2-14
Call Operations2-12
Call Rejection
Calls without Caller ID 11-11
Unknown Callers 11-11
Call Restrictions 11-10
Call Settings 18-9
Call Time 18-9
Call Waiting 2-20
Caller ID 2-3, 2-21
Camera [Section Contents]6-1
Center Access Code 1-28
Channel Setting 5-4
Character Code (Kuten Code)
Character Code List 19-19
Input Options
Charge Limit
Charging Time1-12
Clock Display
External Display
Horizontal Open Position 18-13
Internal Display
Closing Clamshell 18-9

Color Scheme	. 18-3
Confirming Settings	18-24
Content Key	9-5
Context Forecast	3-6
Continuous Shooting	
Conversion Candidates	
Conversion Methods	3-6
Cookies Setting/Deleting	
Internet	18-20
Mobile Widget	18-15
Copy Protected Files	9-4
Country/Region Code	. 2-10
Customer Service	19-34
Customized Screen	. 1-24
D	
Data Folder	9-2
Data Folder	
Data Folder	. 18-8
Data Folder Date & Time Settings Deleting	. 18-8 . 12-5
Data Folder  Date & Time Settings  Deleting  Calendar events	. 18-8 . 12-5 13-21
Data Folder	. 18-8 . 12-5 13-21 4-9
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4 . 13-9
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4 . 13-9
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4 . 13-9 . 12-9 5-1
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4 . 13-9 . 12-9 5-1 18-14 . 1-10
Data Folder	. 18-8 . 12-5 13-21 4-9 . 15-4 . 13-9 . 12-9 5-1 18-14 . 1-10 . 1-10

Customized Screen	Download
Fonts	Customized Screen 1-24
From web pages	Familiar Usability1-24
Lifestyle-Appli	Fonts1-25
Music	From web pages14-11
Music	Lifestyle-Appli 15-2, 16-3
Templates	
Templates	S! Appli 15-2
Download Dictionary	
Drafts	Widgets 7-3
E  e-Book Viewer	Download Dictionary 3-10
E  e-Book Viewer	Drafts
e-Book Viewer	
e-Book Viewer	_
Earpiece Volume  Video Calls	E
Earpiece Volume  Video Calls	e-Book Viewer7-8
Voice Calls	
Voice Calls	Video Calls2-7
Emergency Calls (110, 119, 118) 2-4	
	Emergency Positioning Request 2-4

Emission OFF Mode ...... 1-18 Event Indicators...... 1-21 External Display...... 1-10, 1-23

F	Н
amiliar Usability	Handset  Menus
G	Video Calls2-12
lobal Roaming Service	Voice Calls
SM 2-11	I
	IC Card Lock

International Setting ...... 2-10

Internet [Section Contents] 14-
K
Key Assignments       Mode 1 (5-touch)
Key Pad Dial Lock       11-         Key Tone       18-         Keyguard       11-         Kuten Code (Character Code)       19-1
Language

M	
Mail Group	13-18
Mail Security	11-10
Main Menu	1-18
Making Calls	
International Calls	2-9, 2-10
Video Calls	2-7
Voice Calls	
Manner Mode 1-17,	2-12, 18-7
Manufacture Number	18-20
Memory List	19-25
Memory Manager (Internet)	18-20
Menu Icons	18-4
Menu Numbers	1-19
Messaging [Section Contents]	13-1
microSD Card	9-16
Backup	9-19
Check	9-21
Formatting	9-18
Synchronizing	
Missed Call Notification	
Mobile Widget	7-2
Mobile W-Speed	5-2
MULTI Key	
Multi Selector	ix
Music folder	
Music Player [Section Contents]	
My original set	
My Pictograms	9-2, 13-6

N	
Network Information	1-16
Network S! Appli	15-2
New Messages	
Receiving	13-15
Viewing	13-10
Night mode	
Camera	6-5
Video Calls	
Normal Mode (Simple Menu)	1-26
Notepad	
Notification Light Settings	18-10
0	
One-push Open Button	4 7
One-push Open button	1-/
Open For New	18-3
	18-3 18-7
Open For New Open-to-Ans. Call	18-3 18-7 2-11
Open For New Open-to-Ans. Call Operator Names	18-3 18-7 2-11 2-17
Open For New	18-3 18-7 2-11 2-17 9-13
Open For New Open-to-Ans. Call Operator Names Optional Services Original Animation	18-3 18-7 2-11 2-17 9-13
Open For New	18-3 18-7 2-11 2-17 9-13 16-1
Open For New	18-3 18-7 2-11 2-17 9-13 16-1 9-3
Open For New	18-3 18-7 2-11 2-17 9-13 16-1 9-3
Open For New	18-3 18-7 2-11 2-17 9-13 16-1 9-3

De consende (Chemeiron)
Passwords (Changing)
Center Access Code 1-28
Phone Password 11-2
Security Code2-21
PC Site Browser 14-2
Access 14-5
Display Settings18-19
Memory Manager & Settings 18-20
Security Settings 18-20
Personal Data Lock11-4
Phone Book [Section Contents]4-1
Phone Password 1-28
Changing 11-2
Photo light setting 6-5, 6-10
Photo mode 6-5
Pictographs3-4
Pictures (Still Images)
Capturing 6-6
Editing9-12
Pictures folder 9-2
PIN/PIN2 1-3
Changing 11-2
PIN Authentication 11-2
PIN Lock & Cancellation (PUK) 11-3
Play Background8-7
Play List
Play mode setting
Predictive Candidates
Privacy Key Lock
Private Menu
PUK/PUK2 1-3, 11-3

	All Reset	11-12
	Browser Settings	18-21
	Settings	11-12
	Total Call Charge/Time	
	TV Settings	18-15
	Ring Songs&Tones folder	9-2
	Ring Time (Answer Phone)	
	Ring Time Settings	
	Ringer Volume	18-2
	Ringtone	
_	Ringtone Duration (Message)	
<u>6</u>	Root Certificates	
<u>e</u>		
Appendix	S	
19	S! Addressbook Back-up	4-10
פו	S! Appli [Section Contents]	
	S! GPS Navi [Section Contents]	
	S! Information Channel	
	5. miormation chamier	

Reset

 QR Code
 12-11

 Quality (Camera)
 6-5

 Quick Open Menu
 19-14

S! Mail 13-2
Creating/sending13-4
Mail Notice13-11
Settings 18-19
Universal Settings 18-18
S! Quick News7-4
Settings 18-16
Save
Alarms 12-7
Calendar Events 12-2
Camera 6-11
Notepad 12-8
Phone Book 4-3, 18-11
S! Information Channel 7-6
S! Quick News 7-4
Shortcut 1-22
User's Dictionary 3-10
Saved Pages14-8
Script 18-20
Scroll Unit18-19
SD Audio8-2
Secret Data Only11-9
Secret Mail Setting11-9
Secret Mode 11-9
Secure Remote Lock 11-6
Security
Data Folder 9-14
Internet 18-20
S! Appli 15-4
Security Code 1-28
Security Functions 11-2
Server Mail 13-14

Settings [Section Contents]	18-1
Shikkari Talk	2-5
Shortcuts	
Shutter sound	6-11
Side-keys Guard	11-8
Signal Strength	1-10
Simple Menu	
SMS	13-2
Creating/sending	13-7
Settings	
Universal Settings	
Snooze	
SoftBank Utility Software	10-11
Softkeys	ix
Software Update	19-12
Sort (Messages)	13-21
Spam Filter	
Speaker ON/OFF	2-12
SSL	14-3
Status Indicators	1-10
Still Images (Picture)	
Capturing	6-6
Editing	
Streaming	
Symbols	
Symbol List	

## Tasks ...... 12-5 Templates (Graphic Mail)......13-5 Text Entry [Section Contents] ...... 3-1 Timer Lock at Close ...... 11-6

URL History	
PC Site Browser	14-
Yahoo! Keitai	14-
USB	10-1
User Mode (Manner Mode)	18-
User's Dictionary	3-1
USIM Card	1-
USIM Card Phone Book	4-
USIM PINS	1-

TLS......14-3 Trimming (Editing Still Images) ...... 9-13

Vibrator	
Incoming alert	18-2
S! Appli	
Videos (Recording)	
Videos folder	
View Blind	1-30
Viewfinder	
Camera	6-4
Video Camera	
Voice Announce	12-10
Voice Dial	4-14
Voice Mail	2-18
Voice Recorder	12-10
Volume	
Ringtone	18-2
S! Appli	18-21
Video Calls	2-7
Voice Calls	2-5

waiipaper	
External Display1	8-
Horizontal Open Position 18	-1:
Internal Display 1	8-3
Narning Messages (PC Site Browser) 18	-19
Narranty19	-33
Weather Indicator	7-
White balance6-5, 6	
Nidgets	7-2
NMA Files	8-
Norld Clock 1	8-

'ahoo! Keitai	14-
Access	14-
Display Settings	18-1
Memory Manager & Settings	18-2
Security Settings	18-2

Zoom	 	 6-

# **Warranty & Service**

## Warranty

Warranty is provided when you purchase a 940P.

- Check name of distributor and date of purchase.
- Read through contents and keep in a safe place.
- The warranty term is described in the warranty.

SoftBank is not liable for any damage resulting from use of this product.

## **After-Sales Service**

- Repairs within warranty are performed under terms and conditions described
- Out of warranty, any repairs are performed upon request at subscriber's expense.

# **Customer Service**

If you have questions about SoftBank handsets or services, please call General Information. For repairs, please call Customer Assistance. Check phone number before you dial.

**SoftBank Mobile Customer Center** 

From a SoftBank handset, dial toll free at 157 for General Information or 113 for Customer Assistance SoftBank Mobile Global Call Center

From outside Japan, dial +81-3-5351-3491 (Please take care to dial the correct number. International charges will apply to this call.)

Call these numbers toll free from landlines.

Subscription Area	Service Center	Toll Free Number
Hokkaido, Aomori, Akita, Iwate, Yamagata, Miyagi,	General Information	0088-240-157
Fukushima, Niigata, Tokyo, Kanagawa, Chiba, Saitama, Ibaraki, Tochigi, Gunma, Yamanashi, Nagano, Toyama, Ishikawa, Fukui	Customer Assistance	0088-240-113
Aichi, Gifu, Mie, Shizuoka	General Information	0088-241-157
	Customer Assistance	0088-241-113
Osaka, Hyogo, Kyoto, Nara, Shiga, Wakayama	General Information	0088-242-157
	Customer Assistance	0088-242-113
Hiroshima, Okayama, Yamaguchi, Tottori, Shimane, Tokushima, Kagawa, Ehime, Kochi, Fukuoka, Saga, Nagasaki,	General Information	0088-250-157
Oita, Kumamoto, Miyazaki, Kagoshima, Okinawa	Customer Assistance	0088-250-113

### SoftBank 940P User Guide

June 2009, First Edition

## **SOFTBANK MOBILE Corp.**

For additional information, please visit a SoftBank shop.

Model: SoftBank 940P

Manufacturer: Panasonic Mobile Communications Co., Ltd.



Please help the mobile industry maintain high environmental standards. Recycle your old handsets, batteries and charger units (all manufacturers and brands). Before you recycle, please remember these important points:

- Handsets, batteries and chargers submitted for recycling cannot be returned.
- Always erase all data recorded on old handsets (Phone Book entries, call records, mail, etc.) before recycling.