


	FUNCTIONAL SPECIFICATION	1
1.	PRODUCT SUMMARY	1
1.1	PRODUCT INTRODUCTION	3
1.2	FEATURE SUMMARY	3
1.3	Product as Received	3
1.3.1	Basic unit	3
1.3.2		3
1.4	REQUIRED PRODUCT APPROVALS	7
1.4.1		7
1.4.2	1 0 0 1 0.11 0 0	7
1.4.3.	CE	7
2.1	PRODUCT OUTLOOK	8
2.2	OPERATIONAL BUTTONS	8
2.3	POWER ON/ POWER OFF	10
2.4	ACTIVATE PAIRING MODE/CANCEL PAIRING	1
2.5	CONNECT MANUALLY/DISCONNECT MANUALLY	1
2.6	DIAL FROM CELL PHONE THROUGH BT1310	1
2.7	ANSWER CALL/REJECT CALL	1
2.8	SWITCH TO FM/CANCEL FM	1:
2.9	TUNING FM/SWITCHING CHANNELS	1
2.10	HANG UP & ANSWER ANOTHER INCOMING CALL	
2.11	PLAY/PAUSE	13
2.12	STOP	13
2.13	NEXT/PREVIOUS SONG	1:
2.14	ADJUST THE VOLUME	1
2.15	USB CHARGING	13

1.	PRODUCT SUMMARY
1.1	PRODUCT INTRODUCTION
listen t calls in allows	SH-1310 STEREO HEADSET and CAR KIT allows you to o stereo sound music from PC, mobile phone and phone orisp high quality audio. With Built-in FM transmitter, it user to hear the music or phone calls via Car Speaker ne Stero.
1.2	FEATURE SUMMARY
1)	Built-in FM transmitter.
a.	Allow you to listen to your music in the cell phone
	through the car speaker.
b.	Allow you to hear the phone calls through the car speaker.
2)	Connectivity
a.	Integrated Bluetooth Technology for wireless
	conenction to the mobile phone
b.	Use CSR chipset as the Bluetooth platform
C.	The connection between mobile phone and BSH-1310 is Bluetooth technology. It uses CSR-BC03 solution, which is V1.2 (CLASS 2).
d.	BSH-1310 is equipped with FM transmitter to connect to your car stereo.
3)	Product specification
a.	Bluetooth Profile supports headsets and handsfree function.
	(1)



POWER ON/ POWER OFF

Power On

2.3


BSH-1310

Cancel FM

2.12

STOP


Press PLAY button once.






1.4.2

FCC







When the unit is off, press down and hold the FM

button for 3 seconds. Then the OLED screen will

light up and show BSH-1310 logo.





When the device has already been paired and connected to your Bluetooth cell phone, you can dial from the cell phone through BT1310 when it's in the standby mode by pressing PLAY once,then press the NEXT and PREVIOUS button to choose the number you wish to call, from the incoming call record list then press PLAY one more time to dial out. Press PLAY button one more time to hang up the call.

8

Note: The numbers you can call out from the cell phone through BSH-1310 are the last nine incoming numbers of the cell phone.

ANSWER CALL/REJECT CALL

Answer call

When the cell phone has been connected with the BSH-1310, and when there is an incoming call, the cell phone will send the call to BSH-1310 and on the screen of BSH-1310 it will show the incoming number.

C1 034266611	-	*
034266611		C1
	034266611	

If you wish to answer the call, press PLAY once to

answer the call.

If you wish to reject the call, press PLAY for two seconds. When the call is being rejected, the screen will switch back to the standby mode. Note: Even if BSH-1310 is in the hibernation mode while receiving an incoming call, the call can still get through to BSH-1310 automatically without any further operation on BSH-1310.

SWITCH TO FM/CANCEL FM 2.8

Switch to FM * 🗆 🔹

If you wish to broadcast the phone call onto the car If you wish to broadcast trie priorie can onto the sale speaker, press FM button once, then press PLAY and it will broadcast your phone call onto the speaker. (Note: If the device is in the hibernation power saving mode, you need to wake it up first.) The "T" sign left

to the battery sign means that it's on the FM mode. (Note: While switching to FM, please wear the headset neck strap for getting the best effect)

9

When the device is in the standby mode, press FM button to enter into the FM mode. Then, press PLAY once to cancel the FM mode. TUNING FM/SWITCHING CHANNELS 2.9 Tuning FM Press FM button to activate the FM mode while the device is in the standby mode. Press "NEXT" and "PREVIOUS" button to tune the frequency. You can also set the current frequency as a preset channel by pressing PLAY button for two seconds. There are a total of 9 preset FM channels. Switching channels When in the FM mode, press "VOLUME UP" and "VOLUME DOWN" for selecting different preset channels. (Note: Please tune to the most proper frequency for getting the HANG UP & ANSWER ANOTHER INCOMING CALL Press PLAY button directly during the conversation, then it will hang up the current phone call and automatically connect to the next incoming call. PLAY/PAUSE Press PLAY button once when in the music playing mode.

(10)

BBluetooth° • C€ • FC • ★ • RoHS

NEXT/PREVIOUS SONG

ADJUST THE VOLUME

the Volume Down button to lower the volume.

USB CHARGING

connecting it to your computer.

vou want to listen to.

Press "NEXT" and "PREVIOUS" button to select the songs that

Press the Volume Up button to increase the volume, and press

The USB connector on BSH-1310 is for charging the device by

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.