

## BT-1390 SYSTEM DIAGRAM

The frequency of the clocks and oscillators: 16 MHz