


# BLUETOOTH HANDS-FREE WITH FM SPEAKERPHONE



## User Manual

All other trademarks included herein are the property of their respective owners.  
The Bluetooth® word mark and logos are owned by bluetooth SIG, Inc.  
(Design and specifications subject to change without notice)



## INDEX


Panel part.....	02
Side part.....	03
ON & OFF.....	04
Pairing .....	04
Opening the FM transmitting function.....	05
Setting the FM frequency.....	05
Closing the FM transmitting function.....	05
Making a call .....	06
Pronunciation dialing .....	06
Last redialing.....	06
Listening the incoming call.....	06
Rejecting the call .....	07
Mute function .....	07
FM Transmitter Function.....	07
Terminating a call .....	08
LED indication .....	08
Fixation of the hands free.....	08
Specifications .....	09

01


02

## Side part

There are six LED display the frequency, they respectively corresponding to: 90MHz, 91MHz, 92MHz, 93MHz, 94MHz, 95MHz. Also with two MIC input, one is for gathering the sound, the other one is for noise suppression & echo cancellation.



3.5 stereo jack is exterior audio frequency input connection, Mini 5 Pin USB socket is for charging. You can charge the hands free by connecting the hands free to car charger via this socket.



03

04

## 3. Opening the FM transmitting function:

When you power on the hands free, it won't enter the FM ON mode immediately, pls switch on the FM by hand. Pls press and hold the S3 key for about 4 seconds then release. The FM LED indicator of the 90MHz will glitter incessantly, it show the FM works at the 90MHz.

## 4. Setting the FM frequency:

In FM works mode, press the S3 key for 1 second, then release, the FM LED indicator will change to the next frequency. Repeat the operation, the FM frequency will be in turn changed, 92MHz, 93MHz, 94MHz, 95MHz then back to 90MHz and in turn repetition.

## 5. Closing the FM transmitting function:

In FM works mode, press the S3 key for about 4 seconds, then release, The FM LED indicator will be extinguished which shows the FM is closed.

05

06

## 10. Rejecting the call:

When there is an incoming call, pls press and hold the S2 key about 3 seconds to reject the calling.

## 11. Mute function

To silent the microphone during an active call, press and hold the S2 key for about 3 seconds, the Silent function is on. When your headset is in the Silent mode, you could repeat the operation or press and hold the S1, the Silent mode is off.



## 12.FM Transmitter Function

The hands free can also be used as FM Transmitter. You can play your music from your MP3 player by connecting your MP3 player to the 3.5 Stereo Jack with audio-in cable supplied in the kit. The hands free will auto switch to incoming call if you pair your mobile to the hands free at the same time.

07

08

See pictures as below:



Ventilation rack clip

Acceptor of car kit

Kit Sunshade panel clip

## Specifications:

Bluetooth version	V2.0
Wireless frequency	2.40-2.48GHz
Transmit range	10 meters
Charging time	about 2 hours
Size	55X56X13.5 mm
Weight	about 50g
Talking time	8 Hours
Standby time	120 Hours

09

10

Operation Temperature	-10°C-50°C
Relative humidity	<65%
FM frequency	88MHZ-108MHZ
Frequency response	20-15KHZ, SNR≥68dB, Stereo Separation>50dB, THD<0.1%, Transmit Level<104dBuV
Transmission range	10 meters
Transmitting frequency	fixed 6 frequency
Battery	5V /300mA / Rechargeable