EXCLUDED BANDS

Band 1 (2,850-3,025) kHz

Band 2 (3,400-3,500) kHz

Band 3 (4,650-4,700) kHz

Band 4 (5,450-5,680) kHz

Band 5 (6,525-6,685) kHz

Band 6 (8,815-8,965) kHz

Band 7 (10,005-10,100) kHz

Band 8 (11,275-11,400) kHz

Band 9 (13,260-13,360) kHz

Band 10 (17,900-17,970) kHz

Band 11 (21,924-22,000) kHz

Band 12 (74.8-75.2) MHz

































