Figure 1 S1613-01 (EUT) cradled in Docking Station (SDS)

Figure 2 EUT removed from SDS

Figure 3 EUT Bottom View

Figure 4 EUT Nameplate label location

Figure 5 EUT Battery removed from slot

Figure 6 EUT Battery module

Figure 7 EUT Battery connector

Figure 8 EUT WLAN Card location
(Black & gray cables go to antennas.)

Figure 9 EUT Memory and RTC backup batteries

Figure 10 AC Adapter