

RF-7550L

Quick Installation Guid

English Quick Installation Guide 1-1

USB Keyboard and Laser Mouse Kit

Cordless keyboard X 1 USB Dongle Receiver X 1

Dimension: 106.0(L) x 68.0(W) x 39.5(H) mm Microsoft system Windows® 8 / Windows® 7 / Windows Vista®(SP2) /









Specification

Interface: Wireless 2.4GHz

Interface: Wireless 2.4GHz

Resolution: 800 / 1200 / 1600 DPI(Laser)

Dimension: About 19.1(L) x 14.65(W) x 6.1(H) mm

Battery Life: Up to 6 Months(4hrs/day)

Effective Distance: About 10 M.

Key number : 6 keys

Battery low indicator

Power ON/OFF switch

Battery: AAA X 2 PCS

Interface : USB

Key number: 104 Keys(By language)

US 1-1

Scissor-structure key-switches Congratulations on your purchase of an i-Rocks RF-6577L. The RF-6577L Battery low / Num Lock / Caps Lock indicator. wireless keyboard and laser mouse combo uses the latest 2.4GHz RF Battery Life: Up to 12 Months(4hrs/day) technology to provide you with extended range and flawless communication Effective Distance : About 10 M between the keyboard, mouse, and your computer. It provides users the Battery: AA X 2 PCS highest performance, quality, and convenience. The RF-6577L keyboard Dimension: 460(L) x 157(W) x 22(H) mm and mouse combo is a perfect choice in your digital life.

Package Contents

Cordless optical mouse X 1 Quick installation guide X 1

System Requirement


Windows® XP(SP3) or later

Available USB Port











(I) · Computer Power OFF Buttor

 Battery low. Caps · Indicate the Caps lock states. Num · Indicate the Num lock states. Num lock Caps lock



US 1-3



DPI Resolution Exchange (1200/1600/800 DPI)

DPI Resolution : 1200 → 1600 → 800

LED Flash Time : Two → Three → One

DPI exchange button

exchange button.

· Press DPI exchange button to change the resolution in a cycle.

· When turn off the power of mouse it will resume 1200 DPL


· LED will flash to show the status of the resolution after pressing DPI

Battery low LED & DPI Indicators



Hardware Installation

1. Set up the Keyboard (Put provided batteries into keyboard's batteries housing) Take the keyboard and make sure the 2 x AA alkaline batteries on the back are installed correctly, replace battery door, (Follow the polarity signs




connector into your PC USB port, wait until automatic installation has 2 Set up the Mouse (Put provided batteries into mouse's batteries housing.)

Open the battery housing cover under the cordless mouse's bottom side.

Install the provided batteries into the battery housing. (Please follow the polarity signs in the battery housing.)

Close the mouse battery housing cover.







US 1-5



donale receiver.

US 1-6

Power ON /OFF Switch

Turn on the power switch on the back of keyboard.

B. Easy automatic wireless connection :

completed.

Check the USB dongle receiver is connected to your computer's USB

 Make sure the mouse and keyboard hardware installation is completed. and keyboard. (The positive (+) and negative (-) ends of each battery must

not using for a long period of time.

All product names are trademarks or registered trademarks of their respective owners.

Microsoft, Windows and Windows logo are trademarks or registered trademarks of Microsoft. Corporation in the

2. Unplug and Plug again the USB dongle receiver into your computer's

3. Waiting for the USB plug and play initialization completed.

The wireless keyboard and mouse were already pairing OK before

shipment. So the user does not need to do any pairing. Once need

to re-pairing, please follow below steps to complete the necessary

ID-Setting process for your cordless mouse/Keyboard and USB

4. For mouse ID setting:

move your cordless mouse and close to the USB RF receiver within 30 cm press Mouse's "Middle Button" & "Right Button" and hold about 5

Connect the USB mini receiver to your computer by plugging in the receiver

Unplug the USB donale then plug in the USB receiver, turn on the power.

5. For keyboard ID setting: Turn your cordless keyboard on and move your cordless keyboard and

close to the USB donale receiver within 30cm, then click the connect button of keyboard to start ID setting process. (It will take about 4~8 seconds waiting time)

6. Ready to use

7. Step 4 and 5 should be finished in 2 minutes If the mouse or keyboard doesn't work properly, please remove the USB dongle receiver from

match the polarity signs in the battery housing)

Reorient or relocate the receiving antenna. Make sure the batteries power qualities are good for use.

following measures:

US 1-8

Make sure the ID Setting process is well completed.

Please change batteries immediately when the cordless mouse scroll wheel glow red or the cursor on screen does not move or move erratically. FCC Caution: To assure continued compliance, (example – use only shielded interface

Please change batteries immediately when the cordless keyboard / authority to operate this equipment. mouse battery low indicator light up. Warning: Please remove batteries from your cordless mouse when

Wireless performance: Metal object close to or in between the device. (Please remove objects.)

Mouse will have reduced tracking performance on very shiny or transparent This device complies with Part 15 of the FCC Rules. Operation is subject to the following two condi-tions:

computer's USB port, then repeat do step 4 or 5 step again.

United Stated and /or other countries.

What do I do if the cordless mouse or keyboard does not work?

Make sure the batteries are correctly installed into your cordless mouse

This equipment generates, uses and can radiated ra-dio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

Olncrease the separation between the equipment and receiver.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B

digital device, pur-suant to Part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation.

to radio or television reception, which can be determined by turning the equipment

off and on, the user is en-couraged to try to correct the interference by one of the

(1) This device may not cause harmful interference, and(2) this device must accept

*사용자안내문: B급기기 (가정용 방송통신기자재)

목적으로 하며, 모든 지역에서 사용할 수 있습니다.

OConsult the dealer or an experienced radio/TV technician for help.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

China Office

Tel:+86-010-56130542 cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's www.i-rocks.cn

> i-Rocks Korea www.i-rocks.co.kr

> > i-Rocks Malaysia

i-Rocks Technology Co., Ltd.

New Taipei City 23146, Taiwan R.O.C.

12F.No.190.Sec.2.Zhongxing Rd.,Xindian Dist.

Headquarter Office

Tel:+886-2-2911-3080

Fax:+886-2-2914-1712

www.i-rocks.com

57-A, Jalan SS21/1A, Damansara Utama, 47400, Petaling Jaya, Selangor, Malaysia

Tel:+603-77339233

www.i-rocks.com

any inter-ference received, including interference that may cause undesired operation.

이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는 것을

20140124



