TV Modulator &BT Adapter Operation Instruction

Thank you for choosing TV Modulator. This product can lead you to high-definition visual and stereo audio world and give your life a new concept. We sincerely hope you are satisfied with our product. Before using, please read the user manual carefully.

1. Function Description:

TV Modulator is mainly used to connect TV, DVD/VCD/IPOD and Pocket (the Bluetooth stereo earphone) wirelessly. It can protect your families or neighbors from the surrounding noises while you are concentrating on watching TV. Its reasonable designing brings you the more comfortable and convenient life and freedom space than forever.









2.View:

Front Panel Rear Panel



CH 3
BT Button
BT LED
TV CH LED
TV Button
TV out
AV input
DC power input
On/Off Switch



3. Installation and Playing Procedures

- 1 Put TV Modulator on the stable place such as the surface of counter or desk
- 2 Plug the power jack into TV Modulator socket or put four AAA dry batteries into the battery slot.
- 3. Pairing wth Bluetooth headphone

VCD/DVD play mode

- 1 Connect VCD/DVD with TV Modulator by the AV cable.
- 2 Turn on the TV Modulator power switch and the red and blue LEDs blinks fast.
- 3 Press the "select channel" button lightly till the red light keeps on constant state, which shows TV Modulator have fixed the frequency.
- 4Select the disk and turn on TV and adjust into the same channel
- 5 Put the Pocket closes to TV Modulator and turn it on by pressing the "power" button till the blue and red LED flash quickly and alternatively.
- 6 Release the button and enter into pairing state automatically.
- 7 The blue LED both on Pocket and TV Modulator flash one time every seconds indicate them have paired successfully

4. Tech-specification:

TV Channel: 3 CH, UHF

Frequency Range: 400MHZ-450MHZ

Bluetooth stereo audio transmitter Compatible BT stereo headphones Compatible Bluetooth 2.0, class 2

Sight of range: 10m (33 feet)

Input voltage: 9 VDC

Operation current: 200MA
Battery: 4 AAA alkaline cells
TV RF output: F connector

AV Input: MINDIN 9 pins

5. Precaution

- **♦** Please use the provided power
- **♦** Please remove off the battery when not use it.
- **♦** Avoid putting the TV Modulator and power in wet place.

6. FCC NOTIFICATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.