



**EUT – Cover off View (2.4GHz Internal Antenna)** 




**EUT – Cover off View (5.8GHz Internal Antenna)** 



**EUT – Power Board Top Components View** 



**EUT – Power Board Bottom Components View** 




**EUT – Control Board Top Components View** 




**EUT – Control Board Bottom Components View** 




EUT – 2.4 GHz Antenna View 1



EUT -2.4 GHz Antenna View 2



EUT – 5.8 GHz Antenna View 1



EUT – 5.8 GHz Antenna View 2

