

1008-00080

**Revision 1.0** 

WF-10040
Label Placement Instructions

TITLE: WF-10040 WiFi Module Labeling Instructions

AUTHOR: Scott Lyle Date: 6/17/2014

REVISION: 01

## **TOOLS REQUIRED:**

ESD Wrist Strap 2110-00168 FCC/ICID Label for WF-10040 WiFi Module Tweezers for applying label

**STEP 1:** Locate the Jorjin module on the PCB. The module will look like the Jorjin module in picture below.



STEP 2: Apply the FCC/ICID Label (2110-00168) as shown.

