FMT-MB02 rev. 3

THG4649 demonstration set Operating Manual



1. Turn on the power supply of kit by battery box's ON/OFF switch



- 2. Set starts the FM transmission based on latest setting data
- 3. Select frequency value by Up/Down button
- 4. Change to the next frequancy. 88.1 ⇔ 88.2 ⇔ ** ⇔ 107.8 ⇔ 107.9 ⇔ 88.1

-SPEC

Antenna:Built-in

POWER: Battery 3V (R6 x 2) Modulation: FM Stereo Frequencies: 88.1 -107.9MHz

Oscillator: High stability crystal oscillator, phase-lock loop control

Frequency response:50Hz to 15KHz

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference,

and (2) this device must accept any interference received, including interference that may cause undesired operation.