Instruction Manual for R/C Tipcart Series










1.is not suitable for the 3 years old and the following child

2.Before beginning uses must bard finish reading this manual

3.Suggestion is under the person's leading usage


- NO:9808-8
- NO:9808-5
- NO:980B
- NO:9802


CHARACTERISTIC




Remote control









in the transmitter







9808-5 Chassis


9808 Chassis

- 1. Four passages, many functions, can make the every kind of stunt action of vacillating etc.
- Use reachingeable batteries or alkaline batteries.
- 3. The bedrock establishes to refresh the socket and can directly refresh on the car.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authorization to operate the equipment.


CHRGING


- 1.Pluy the charger to an indoor 220V(110V). AC power socket.
- 2.Pluy the outlet line of the charger to the charging jack underneath the car.
- 3.9808 9802 Set the power switch underneath the car to ON.(Note: This step is necessary. Otherwise, charging won't be possible.)
- Optimum charging time is 6 hours.




SAFE RULE

- While playing indoors, take care not to damage furniture or glass articles.
- 2.Do not play with this product on roads or in a crowded place to avoid dangers.
 - To play outdoors, please choose a safe place.
- While playing outdoors, immediately stop playing whenever thunder is heard.
- 4.Do not play with this product in a wet or sandy place to avoid circuit malfunction.
- 5.Do not bend the antenna. If the antenna is broken, its sharp ends may cause hurts.
- 6.Do not pull the wires in the car. If the wires are broken, the car may lose its normal functions.
- Keep fingers, hair and clothes away from spinning tyres. Otherwise, they may be entangled into the tyres, causing hurts.
- 8.Do not control the car to run at people.
- 9.Do not throw or bump the car around.
- 10. Store the car away from fire source or high temperature environment.
- 11. This product contains complex electronic circuit and numerous electronic components. Do not try to detach or modify the circuit board.
- 12. When the battery power in the car or controller becomes insufficient, the car may obviously slow down or become out of control. In such case, please replace the batteries with new ones,
- Operating in the following ways can prolong the batteries' lifespan: a) Remove the batteries before long-time storage, b). When it's time to replace batteries, replace them all at a lime. If new and old batteries are mixed for use, all the batteries may soon become out of power.





- 1.pull up the remote control antenna;
- 2.press to move the remote control key to then direct the car to drive with do the every kind of stunt action.



Note:If the car soon become slow,not easy and vacillating, just electric power lack, need to be refreshed.