# GPRS Module / POS Terminal

## (M/N: GPRS Module H50-CM06/ POS Terminal H50-10)

Test Mode: Mode 1: GPRS 850

Description: ERP Test Setup

Test Mode: Mode 2: GPRS 1900

Description: EIRP Test Setup

Test Mode: Mode 1: GPRS 850

Description: Substitution Antenna for ERP Test

Test Mode: Mode 2: GPRS 1900

Description: Substitution Antenna for EIRP Test


Test Mode: Mode 1: GPRS 850

Description: Radiated Spurious Emission Test Setup

Test Mode: Mode 2: GPRS 1900

Description: Radiated Spurious Emission Test Setup

Test Mode: Mode 1: GPRS 850

Description: Substitution Antenna for Radiated Spurious Emission Test

Test Mode: Mode 2: GPRS 1900

Description: Substitution Antenna for Radiated Spurious Emission Test