Device connection and setup

PC
DCNM-CBXX
DCNM-APS
PoE Switch
DCNM-IDESK

See IM: Installation Manual
See CM: Configuration Manual

DCNM-IDESK
DCNM-IDESKVID
HDMI
DCNM-IDESK

DCNM-CBXX
DCNM-APS
PoE

CAT-5e cable
DCNM-APS
PoE Switch
PoE

DCNM-APS / DCNM-PS
PoE

See IM: Installation Manual

Additional information

For product related information, free software download and documentation, visit:
www.boschsecurity.com

For the latest software versions, go to:
https://licensing.boschsecurity.com/software

For China ROHS, see:
http://cn.boschsecurity.com/rohs

Intentionally left blank

Interpreter desk DCNM-IDESK / DCNM-IDESKVID

BOSCH

en Quick Installation Guide