EUT Position: X-axis




EUT Position: Y-axis




EUT Position: Z-axis



Test Setup Photo of Radiated Measurement (0.009 \sim 30MHz)



Test Setup Photo of Radiated Measurement (below 1000MHz)



Test Setup Photo for AC Conducted Emissions



