## ROMOTE-CONTROL OPERATIONAL DESCRIDPTION

1. Supply voltage: DC 3V

2. Frequency of operation: 433MHz

3. Number of channels: 14. Antenna type: Helical wire

5. Antenna gain: 0dBi

6. Antenna connector: NONE(soldered on PCB)

7. Introduction of the device: The device is used to control Christmas lights, the buttons "on" and "off" on the EUT is for turning the lights on and off.

8. Related antenna connector photo:



