



Model: AL - WB08

User manual


# **Table of Contents**


1. Safety precautions	3
2. What's in the box?	4
3. Product diagram	5
4. Features	6
	6
6. Using your keypad	7
7. Using your mouse	8
8. System requirements	8
9. Specifications	8
10. Limited warranty	8
	9
12. Function table	10

# 1. Safety precautions

- Never open the cabinet under any circumstances. Any repairs or internal adjustments should be made only by qualified service personnel.
- Never operate this product with the cabinet removed.
- Do not use your unit immediately after transporting it from a cold place to a warm place, as condensation may cause the system to malfunction.
- Keep your unit away from humid areas and abnormally hot places.
- Do not touch the unit with wet hands. If any liquid enters the unit cabinet, take the unit to qualified service personnel for inspection.
- DO NOT use liquid and gaseous detergent to clean the unit as it may cause damage to the unit.
- Do not drop or knock the unit, violent action would undermine the internal component.

Congratulations! With the purchase of an Ality weeBoard<sup>TM</sup> Wireless Keyboard, you are about to begin the enjoyment of this product for all basic keyboard and mouse function. Please read these instructions carefully before starting operations. Following the instructions in this manual will enable you to obtain optimum performance from your weeBoard<sup>TM</sup>. Please retain this manual for future reference.






#### 4. Features:

- Fully function of keyboard and mouse with 2.4GHz wireless
- 2.4GHz wireless receiver USB Dongle
- Windows media player control shortcut keys
- Built-in Lithium rechargeable battery
- Up to 10 meters control distance
- Plug and play

#### 5. Installation

- 5.1 Battery charge
  - Plug the USB cable into a USB port on your desktop or laptop computer.
  - Plug the USB cable into the USB port on the upper side of weeBoard<sup>TM</sup> Wireless Keyboard. (A full charge is about 3 hours)



#### 5.2 Connect USB dongle

- Plug the USB dongle into a USB port on your desktop or laptop computer.

# 5.3 Power on unit

- Move the power switch to ON. The computer automatical detects your device.

(Or push it into pair mode by holding the "ESCAPE" and "RIGHT CLICK" buttons together around 5 seconds, and backlit keyboard will flash. The computer automatically pairs the unit.)

Remark: Without using the unit, user may turn off it by "ON/OFF" switch to conserve battery power.

### 6. Using your keypad

- 6.1 Use the keypad to enter data. (Detail refer to function table.)
- 6.2 Press FN plus another key to enter a special character or apply a special function. (Detail refer to function table.)



6.3 Press media player shortcut keys on the top to control media player playback. \*\*base on standard media player\*\*



6.4 Press volume control shortcut keys on the top to control volume.



### 7. Using your mouse

7.1 Use the track pad to move the cursor.

7.2 Press the track pad to perform standard left mouse click, and press right click button to perform standard right mouse click.



7.3 Hold FN key plus use the track pad for scroll function Remark: Detail setting refers to your OS system - mouse properties

#### 8. System requirements

Windows 2000, Windows XP, Windows Vista, Windows 7, Linux and MAC

#### 9. Specifications:

Worldwide 2.4GHz ISM band operation

- Dimension : 129x13x86mm [WxHxD]

Weight : 110g

- Operation temperature : 5 ℃ to 40 ℃

- Battery : Lithium polymer battery 3.7V 900mA

### 10. Limited warranty

Our company will repair the product against troubles arising under normal use and operation conditions (non man-made problems such as abuse and misuse) for a period of one (1) year from the date of original purchase (warranty period).

Our company is not responsible for malfunction due to indirect, special and accidental causes.

Service / repair charges apply to the following conditions within

A. Malfunction due to misuse (not following instructions in the user

B. Damage due to impact.

C. Damage caused by service performed by anyone other than our

D. Malfunction due to connections with other equipment.

E. Damage due to fire, natural hazards etc.....

### 11. FCC notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# 12. Function table

Key function	Press (SHIFT) +	Press (FN) +
ESCAPE		
System media player		
Previous track		
Play/Pause		
Stop		
Next track		
Volume mute		
Valume down		
Volume up		
RIGHT CLICK		
1	. 1	F1
2	@	F2
3	#	F3
4	\$	F4
5	%	F5
6	Α	F6
7	&	F7
8		F8
9	(	F9
0	)	F10
q	Q	
w	W	
	E	
0	R	
r.	T	141
t	Y	
У		-
u	U	- 1
	1	
0	0	-
р	Р	1
a	A	
5	O P A S	
d	D	
1	F	

Key function	Press (SHIFT) +	Press (FN) +
9	G	
h	H	
1	J	
k	J K	?
T.	L	1
Up	-	
Z	Z X C V B	
×	X	
С	C	
V	V	
b	В	
n	N	- 2
m	M	<
	>	>
Left		_
Down		+
PAGE UP		
@		
TAB		
CAP		
PAGE DOWN		
FN		
SHIFT (left)		
CTRL		
Call system start function		
Space bar		
BACKSPACE		
ENTER		
DEL		
Right		=
FN		
ALT		
SHIFT (right)		
And in case of the last of the	8	
Left click (Press trackpad)		

#### FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

#### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.