

Ages 4 and up

WALKIE-TALKIES

Important: Please save this instruction sheet. It contains valuable product information.

## **Battery Safety Information:**

- · Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- · Remove dead or exhausted batteries.
- Connect battery terminals to battery clip correctly.
  Do not force into place.
- · Do not place anything across the battery terminals.
- Only use the batteries specified above.
- We recommend you use alkaline batteries. Rechargeable batteries may affect performance.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- · Do not mix old and new batteries.
- Do not dispose of batteries in a fire; they may explode.
- · Dispose of batteries safely.
- · Do not use rechargeable batteries.
- Only the batteries of the same or equivalent type as recommended are to be used.
- The supply terminals are not to be short-circuited.



Requires two 9-volt batteries, one for each Walkie-Talkie (not included).

- Use a small Phillips head screwdriver to loosen the screw in the battery compartment door on the back of each Walkie-Talkie (Figure A). Unclip the door.
- Snap the battery clip on the battery and place inside compartmen (Figure B).
- 3. Replace the battery compartment door and tighten screw.

## To Operate Walkie-Talkies

1. Turn the On/Off switch to ON.

NOTE: BOTH WALKIE-TALKIES MUST BE SWITCHED ON TO TALK.

- 2. To talk, press and hold the talk button. Release the talk button to listen.
- To call, hold press the call button while holding down the talk button.
- 4. Slide the On/Off switch to OFF after use.

## Notes

- Be careful not to talk at the same time as your friend. Two people talking at once will affect the Walkie-Talkie performance.
- Remember to switch the Walkie-Talkie OFF after use to conserve battery life.



National Geographic's net proceeds support vital exploration, conservation, research, and education programs.

Experience the new National Geographic Channel. Call your cable or satellite provider for availability. Visit our website: www.nationalgeographic.com/kids

©2002 National Geographic Society

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.





fig B

## △ WARNING:

CHOKING HAZARD: Small Parts. Not for Children Under 3 Years.