You can connect many types of external equipment to your TV. To view external source images, select the input source from <SOURCE> on the remote control or on the TV.

#### 2-1. Preparation

Before connecting your TV to external equipments, please refer to following instructions.


#### Before Connection:

- 1. Please read the relevant operation manual (DVD player, etc.) carefully before making connections.
- 2. Refer to your external equipment operation manual for the signal type.
- 3. Whenever you connect an audio or video system to your TV, ensure that all elements are switched off.
- 4. When connecting an external device, match the color of the connection terminal to the cable.

#### 2-2. Connecting Power

- 1. You can use the TV in USA (ATSC & NTSC area).
- 2. The TV automatically adjusts voltage.
  - Before connecting power, please check your power adapter type for wall outlet connection.
- 3. Power cable should be firmly connected to the wall outlet and DC adapter in order not to be pulled out or shake.

### 2-3. Connecting TV Antenna




- 1. Connect RF cable to TV < ANTENNA> & < CABLE> input connector with an outdoor or wall outlet antenna output.
  - For watching analog TV, please connect wall outlet with [Cable] input.
  - For watching digital TV, please connect wall outlet with [Antenna] input.
- 2. Turn on the TV after all connection.

#### Watching Analog TV & Digital TV

Analog TV signal has its channel number structure of 1, 2, 3, 4, 5, etc., but Digital TV signal has its channel number structure of 1-1, 2-1, 3-1, 4-1, 5-1, etc.


If you press TV button on the remote control, its input source chances from Analog to Digital or Digital to Analog

## 2-4. Connecting Video / S-Video




- Connect Video/Audio cable and S-Video cable to video port of the TV and camcorder, game machines, VCR, DVD player or Set-Top box.
- 2. Cables must be connected to ports of the same colors.
- Video & S-Video use same audio line, so if you connect different external equipments with video & S-Video, you can listen only one sound of two different equipment.
- Press SOURCE button on the remote control and select Video or S-video.
   # Video, S-Video and audio cables are not included.

### 2-5. Connecting DVD



- 1. Connect component cable to component ports of TV and DVD player, VCR, Set-Top box or camcorder.
- Cables must be connected to ports of the same colors. # Component and audio cables are not included.

## 2-6. Connecting HDMI




- 1. Connect HDMI cable to HDMI ports of TV and DVD player, VCR, Set-Top box or camcorder.
- If you would like to connect DVI of external equipment to the TV, you must use specific DVI to HDMI cable. # HDMI and audio cables are not included.
- ► For watching digital (DVD, Camcorder, etc) signal;
- 1. Press Source button on the remote control and select HDMI.
- 2. Go into SETUP menu (MENU-> SETUP-> PC/Settop Mode) and select <Settop>.



#### **d CAUTION**:

- 1. HDMI does not support PCM (Pulse Code Modulation) type. (It does not support 5.1 CH Dolby Surround.)
- 2. If you select Dolby system on your AV equipment, there will be no sound.
- 3. HDMI supports up to Ver. 1.1.

## 2-7. Connecting PC




- 1. Connect D-Sub cable to D-Sub port on the TV and PC.
- Connect audio cable to audio output of a PC (stereo jack) and PC audio input port of the TV. # D-Sub & stereo cables are not included.

#### ONOTE:

# Optimal Resolution is 1024 X 768 @ 60Hz.

- ► For selecting PC input source;
- 1. Press PC or Source button on the remote control to select PC (RGB) source.
- ☞ NOTE : Select PC mode on the menu (Menu->Setup->PC/Settop Mode).

### 2-8. Connecting Lineout (External Speaker)



- 1. Connect External Speaker to the Lineout port of the TV.
- 2. Please use 8ohms impedance headphone or external speaker. Otherwise output volume may be too low or too loud.
- 3. In case of connecting to speakers, connect speakers with amps. If connected with speakers without amps, the output volume may be low.

## 2-9. Source Selection

- 1. Press SOURCE button on the remote control and select input source.
- 2. Each time SOURCE is pressed, source item toggles between <TV  $\rightarrow$  DTV  $\rightarrow$  VIDEO  $\rightarrow$  S-VIDEO  $\rightarrow$  RGB  $\rightarrow$  HDMI  $\rightarrow$  COMPONENT>.
- 3. If you would like to select input source without changing screen image, press SOURCE button and move to your wishes input source by pressing 

  ✓/▶ /▲ /▼ buttons and enter (♣) to select.





# Specification

| Product Name           |                         | 15inch TFT-LCD TV          |
|------------------------|-------------------------|----------------------------|
| LCD Panel              | Туре                    | Amorphous Silicon TFT-LCD  |
|                        | Size                    | 15inch (diagonal length)   |
|                        | Resolution              | 1024 (H) x 768 (V)         |
|                        | Pixel Pitch             | 0.297mm x 0.297mm          |
|                        | Contrast Ratio          | 500 : 1                    |
|                        | Brightness              | 450cd/m <sup>2</sup>       |
|                        | Active Area             | 304.1mm x 228.1mm          |
|                        | Viewing Angle           | L/R: 120° / U/D: 100°      |
| TV Broadcasting System |                         | VHF: 2~13 UHF: 14~69       |
|                        |                         | Cable : 1, 14~135          |
|                        |                         | ATSC/QAM Digital Channel   |
| Audio Output           |                         | 3W x 2 / Stereo & MTS      |
| PC Monitor             | Horizontal Frequency    | 30 ~ 61KHz                 |
|                        | Vertical Frequency      | 60 ~ 75Hz                  |
|                        | Colors                  | 16M colors (6bit with FRC) |
|                        | Optimal Resolution      | XGA: 1024 (H) x 768 (V)    |
| Power                  | Adaptor Input           | 100V ~ 240V (Free Voltage) |
|                        | Adaptor Output          | DC 12V                     |
| Power Consumption      | In-Operation            | < 50W                      |
|                        | Power-Saving Mode / OFF | < 3W                       |
| Energy Saving Mode     |                         | VESA DPMS                  |