KOMMTAC

KBD401

USB Bluetooth Dongle

User Manual

For Windows 7 / 8 OS

Regulatory Compliance



FCC ID: VH9KBD401

CE2200

Modification not expressly approved by the manufacture could void the user's authority to operated the equipment under FCC rules.

About This guide

This user guide contains information that you need to install and configure the KoamTac USB Bluetooth dongle.

How this guide is organized.

This guide contains the following parts:

• Chapter 1: Knowing your USB Bluetooth dongle

This chapter provides information on the package contents, system requirements, and specifications of the KoamTac USB Bluetooth dongle.

• Chapter 2: Getting started

This chapter describes how to install.

• Chapter 3: Pairing with a Bluetooth device

This chapter describes how to pair your computer with another Bluetooth devices.

• Chapter 4 : Appendices

This chapter provides you with the regulatory Notices and Safety Statements.

Package contents

- KoamTac KBD401
- Quick Start Guide

System requirements

Before using your KBD401 USB Bluetooth dongle, ensure that your system meets the following requirements:

Operating system: Microsoft Windows 7 / 8

System memory: 512MB or larger

Hard drive free space: 10MB

KBD401 specifications summary

| - | |
|---------------------|--|
| Feature | Compliant with Class I Bluetooth v2.0 and v2.1 |
| | Enhanced Data Rate(EDR) support |
| | Adaptive Frequency Hopping(AFH) support |
| Chipset | CSR8510 |
| Bluetooth Standards | Class I Bluetooth v2.1 + EDR |
| | Bluetooth 4.0 |
| Interface | USB 2.0/1.1 |
| Antenna | Internal |
| Range | Up to 30 meters(depending on the environment) |
| Bluetooth Profile | SPP, HID, DUN, PAN, HCRP |
| Radio Frequency | 2.4 GHz - 2.4835 GHz |
| Transfer Rate | Up to 3.0Mbps |
| OS support | Windows 7/8 |
| Power Consumption | 5V, 90mA max |
| Input Power | 5V (USB bus-powered) |
| Physical Dimensions | 22mmx15mmx5.35mm (LxWxH) |
| Weight | 2.0g |

^{*}Specifications are subject to change without notice.

Getting Start


To install the Bleutooth driver to your computer.

- 1. There is no driver CD cause Windows will install "Generic Bluetooth Radio" driver automatically.
- 2. Insert USB BT Dongle into your computer's usb port.
- 3. Computer will display below message.





 If driver install successfully, you can find the device in device manager (Click Start > Control Panel > Hardware and Sound > Device Manager)




Pairing with a Bluetooth Device


1. Click Bluetooth icon on tray.




2. Click Add a Device menu



3. Select Bluetooth Device on the list.




4. Select Next.




5. Finish Add a Device

Find Bluetooth Serial Comport


1. Enter Bluetooth device list via "Show Bluetooth Devices" menu



2. Select Bluetooth device to find serial comport #



3. Click right mouse button and click Properties menu



4. Select Hardware tab menu. You can find Bluetooth device's serial comport #.

