


## Trouble Shooting

Trouble	Possible Cause	Solution
Too slow to roll or slow roll	Insufficient battery power.	Recharge the battery, or replace with the new battery.
Can't turn over and rise		
Car becomes out of control.	Insufficient power in controller battery.	Replace with a new 9V battery
	Another car is using the same frequency nearby.	Change to another place.



R/C Stunt Car Series — Invincible Wind and Fire Wheel Model No.: 80801BL Series



## To charge battery

Changes or modifications not expressly approved by the party responsible for compliance could void the use's authority to operate the equipment.

## Attentions

Attentions when playing

It will be dangerous to play toy on highways and crowded places. Please

Note that the tallignous to play of might any state cower places. These select safety sites for outdoor playing

Do not bend down antenna, edge of broken antenna may have you hurt.

For indoor players, be note that not to break glasses or home appliances. Be careful when wheels revolving, do not have your fingers and hair hurt. Playing and Maintenance
A. This toy is not suitable to children ages under 3. Do not swallow small

parts from this toy.

- B. Do not play outside when raining or wet places. For car will be short circuited or operation failure if getting wet.
- C. Do not play outside if thundering.
- D. Avoid playing in sands or dusty areas.
- E. Do not dispose in water, fire or dismantle welding parts.
- F. Do not keep this product near fire, wet places or places with high temperature.
- G. Clean this product with dry cloth, do not clean it with water or any
- H. Do not litter packing stuffs unpacked from this toy.

Normal operation is ensured within the control range when there is no interference wave.

Do not use cars of the same frequency at the same time.