Description for operating function

- 1. Power supply: 12VDC
- 2. Operation frequency: 27.145MHz;
- 3. Rated Sending Power: 80dB µ V
- 4. Turn on the power switch
- 5.Press JZ1、JZ2、JZ3; controlling forward ,left turn \ right turn
- 6. Tx-2 send out remote control coding signal, through magnifying circuit and carrier wave, with sending circuit and antenna.
- 7. Push stick channel 2 up to control the airplane to fly up and forward; push stick channel 1 right or left to control the airplane to fly right or left
- 8. Turn off power switch
- 9. This car is a high-speed model, any may turn over when running on uneven ground or turning at high speed.
- 10. This car requires a comparatively large turning diameter when turning
- 11. Advance: push the left lever forward. The two motors will start spinning at full speed, pushing the car forward.
- 8. The controlling distance of the boat is about 50m; do not allow the boat to go beyond this distance to avoid losing its control
- 12. If you find the boat slows down, please immediately control it go to go back, otherwise, you may lose its control due to insufficient.
- 13 this controller uses 8 AA batteries (NI- cd or other types) or 9.6 V power pack
- 14 if the battery power has been used up, it needs 2 hours to fully charge the battery .if there is still power in the battery , charging time can be shortened accordingly.(when the battery surface becomes a little hot, it means it's already fully charged.