Specification and debugging Method for Portable Radio

1 Debugging tools

1) Integrated tester 8921; 2) PC and installed CPS software; 3) AEROFLEX 3920; 4) Spectrum Analyzer FSU.

2 Debugging Method & Requirement For TX section

Item	Instrument Configuration	Measuring		Methods and tools			
		Test Device	Test Point	Assistant tool	Steps	Specification	Remarks
1. Frequency stability	Set 8921 to TX mode	8921	Connect Portable Antenna port to RF IN/OUT port of 8921	PC	1) Open CPS software and enter testing mode. 2) Double click Frequency stability; 3) Adjust the data value of software & Observe the Frequency via 8921; 4) Adjust till Frequency reach 480MHz±1kHz; 5) Click OK to save data.	≤2.5ppm	Within ±1kHz while in testing mode
2. TX power	Set 8921 to TX mode	8921			1) Open CPS software and enter testing mode. 2) Double click TX High Power, Click F1 to F8 separately; 3) Adjust the data value of software & Observe the TX power via 8921; Make the power reach 2W; 4) Observe the Current flow; 5) Click OK to save data.	Power: 2W (H); 1W (low)	Power requirement only apply to Manufacturing Process