Thank you for purchasing the Digital Printer KIP 9000.

This USER'S MANUAL contains functional and operational explanations for the KIP 9000.

Please read this USER'S MANUAL carefully before using the Printer.

Please keep this USER'S MANUAL for future reference.

#### When this machine is installed in USA

FCC ID: VP8-K115

This equipment satisfies the requirements in Part 15 of FCC Rules for a Classic A computing device. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

In order to comply with FCC radio-frequency radiation exposure guidelines for an uncontrolled exposure, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC 15.105(a)

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC 15.21

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### When this machine is installed in Canada

IC Company No. & UPN No.: 7391A-K115

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### When this machine is installed in Europe

This equipment satisfies the requirements in Pub.22 of CISPR Rules for a Classic B computing device. Operation of this equipment in a residential area may cause unacceptable interference to radio and TV reception requiring the operator to take whatever steps are necessary to correct the interference.

Do not install this machine around electronic equipment or precision instruments. Other devices may be effected by electrical noise during operation.

If Machine is installed near other electronic equipment, such as a TV or a radio, interference to said equipment, such as noise or flickering, may occur.

Use a separate power line and install the PRINTER as far as possible from said equipment.

As an ENERGY STAR ® Partner, Katsuragawa Electric Co., Ltd. has determined that this product meets the ENERGY STAR ® guidelines for energy efficiency.



The International ENERGY STAR ® Office Equipment Program is an international program that promotes energy saving through the penetration of energy efficient computers and other office equipment. The program backs the development and dissemination of products with functions that effectively reduce energy consumption. It is an open system in which business proprietors can participate voluntarily. The targeted products are office equipment such as computers, monitors, printers, facsimiles, copiers, scanners, and multifunction devices. Their standards and logos are uniform among participating nations.

1

The symbol shown indicates that this product conforms to Directive 2002/96/EC of the European Parliament and the council of 27 January 2003 on waste electrical and electronic equipment (WEEE) and does not apply to countries outside of EU.



The symbol shown indicates that this product conforms to SJ/T11364-2006 of People's Republic of China Electronic Industry Standard and does not apply to countries outside of People's Republic of China.





The symbol shown indicates that this product conforms to GB 18455-2001 11364-2006 of National Standard of the People's Republic of China and does not apply to countries outside of People's Republic of China.





### A NOTE

KIP 9000 will not function if no optional device is connected. Please ask the Service Personnel for the optional device.

> 9000um0e2 2

### **Safety Warnings**

The following warnings are very important in order to safely use this product.

These notes are very important in preventing danger to the operator or operation of the printer.

The following symbols are found throughout the USER'S Manual and have the following meaning:



### **WARNING**

This WARNING mark means that there is a possibility of death or serious injury if you ignore or do not follow the said instruction.



### **CAUTION**

This CAUTION mark means that there is a possibility of injury or physical damage if you ignore or do not follow the said instruction.



When marked with this symbol, "DO NOT ATTEMPT"



When marked with this symbol, "pay close attention to"

3 9000um0e2



## **WARNING**



Ground the product with a correct ground source or you may be electrically shocked.



- Connected outlet must satisfy the following condition.
   U.S.A. / Europe 220 240V (+6% / -10%), more than 16A, 50/60Hz
- 2. Use a circuit with an exclusive breaker.
- 3. Install the machine as close to the wall outlet as possible.
- 4. If you wish to move the printer, please contact to your service personnel.



- 1. Do not remove the screw and do not open the cover if not instructed to do so in this User's Manual. If you ignore this warning, you may be burnt or receive an electric shock due to a hot item or electrically charged part inside of the printer.
- 2. Do not disassemble or tamper with the printer. It may result in a fire or electrical shock.



- 1. Do not plug in the printer into a multi-wire connector in which some other equipment is plugged into.
  - It may cause a fire due to outlet overheating.
- 2. Do not damage the Power Cord by stepping on or placing something heavy items on it.

If the Power Cord is damaged, it may cause a fire or you may receive an electric shock.

REPLACE THE CORD IF DAMAGED.



- 1. Do not PUT a flower vase, a flowerpot or any water-filled item on the product. Spilt water could cause a fire or an electric shock.
- 2. If the product generates an abnormal smell or noise, turn it off and unplug it from the wall outlet immediately.



Do not throw the toner into a fire or other sources of heat, as it can explode.

4

9000um0e2



# CAUTION



Do not install the machine in a humidified room or a dusty room. Also, do not install the machine on an unstable floor as injuries may occur.



- Unplug the printer before you move it.
   The power cord may be damaged and it may result in a fire or electric shock.
- 2. If you do not use the printer for a long duration (holidays, company shutdown) turn off and unplug the printer from the outlet for safety.



Do not pull the cord when you unplug the printer as you may damage the Power Cord.

Make sure to unplug the plug from the plug case.



There are hot items inside of the machine.

Take great care not to touch these items when you remove mis-fed media.



Ventilate the room well if you print in a small area.

5 9000um0e2

### **TABLE OF CONTENTS**

### **Chapter 1 Before Use**

1.1	Installation Requirements	Page 1- 1
1.2	Originals Prohibited from Duplication	1- 2
1.3	Features	1- 3
1.4	Specifications	1- 4
1.5 1.5. 1.5. 1.5. 1.5.	Right side view Rear view Operation Panel Media Indicators	1- 6 1- 6 1- 7 1- 8 1-10 1-12
1.5.	6 "in use" Indicators	1-13

## **Chapter 2 Basic Operations**

2.2 Turning off the KIP 9000	2-2
2.3 Setting the Roll Media into Roll Deck	2-3
2.3.1 Roll Deck 1, 2 & 3 2.3.2 Roll Deck 4	
2.4 Setting Cut Sheet Media to Bypass Feeder	2-12
2.4.1 Multi-feeding of cut sheet media	2-13
2.4.2 Singular feeding of cut sheet media	2-14
2.5 Replacing the Toner Cartridge	2-16
2.6 Dehumidifying the Roll Media	2-21
2.7 Initial Cut (Straighten the leading edge of roll media)	2-23
2.8 User Modes	2-25
2.8.1 User Mode 1 (Test Print)	
2.8.2 User Mode 2 (Calendar setting)	
2.8.3 User Mode 3 (Warm Sleep Mode ON / OFF & timer setting)	2-34
2.8.4 User Mode 4 (Cold Sleep Mode ON / OFF & timer setting)	2-38
2.8.5 User Mode 5 (Automatic paper cut at power ON)	
2.8.6 User Mode 6 (Transfer Support LED ON/OFF [Film])	
2.8.7 User Mode 7 (Alarm ON / OFF)	
2.8.8 User Mode 8 (Choice of Standard Print Mode /Special Print Mode [Plain paper])	
2.8.9 User Mode 9 (Choice of Standard Print Mode /Special Print Mode [Tracing paper])	
2.8.10 User Mode A (Choice of Standard Print Mode /Special Print Mode [Film])	
2.8.11 User Mode B (Enhancement of isolated dot image)	
2.8.12 User Mode C (Enlargement of trailing image area)	2-64
2.8.13 User Mode F0 to Fb (Setting of folding method	2-68

6

## **Chapter 3 Error Corrections and Maintenance**

		Page
3.1 Me	dia Mis-feed Errors	3- <b>1</b>
3.1.1	Mis-feed in Roll Decks (J-01, J-02, J-03 & J-04)	3- 2
3.1.2	Mis-feed in the Bypass Feeder (J-05)	3- 5
3.1.3	Mis-feed between Cutter and Drum (J-11)	
3.1.4	Mis-feed on the Internal Transportation Unit (J-12) and	
• • • • • • • • • • • • • • • • • • • •	Before the Fuser Unit (J-13)	3-10
3.1.5	Mis-feed After the Fuser Unit (J-14)	
3.2 Op	en Errors	3-24
3.3 Se	rvice Call Errors	3-27
3.4 Int	erruption of Print by Temperature Control	3-28
	Interruption of print by changing the temperature	
3.4.2	Interruption of print by recovering the temperature	
3.5 Ma	intenance	3-30
3.5.1	Cleaning the Image Corona	3-30
3.5.2	Cleaning the LED Head	3-31

7 9000um0e2