

NOTES:

- 1- PLUG TRANSMITTER CABLE FROM THETOP COVER ASSEMBLY INTO THE CONNECTOR ON BOTTOM PCB. 2- MOUNT TOP COVER ASM AND SCREW IT INTO THE
- BASE.
- 3- INSTALL THE THREE LABELS AS SHOWN ON RIGHT VIEW.





DO NOT SCALE	- ⊕ - €	THIRD ANGLE Sheet 3 o			et 3 of	3
MATERIAL: FINISH:	TOLERANCES (EXCEPT AS NOTED)	XCEPT AS NOTED)				
This document, all information contained herein and all information related thereto, is the property of Dynalco Controls a unit of Crane	DECIMAL ±.01 .XX ±.005 .XXX	DATU	260 9260 \XM	SCALE IT2	APPROVED BY	PF DW
Company, is confidential to it and no part thereof nor any such information may be copied,	FRACTIONAL ± 1/64	FINAL ASM, TRANSMITTER 2				
dsseminated or used in any manner whatsoever without the prior written consent of Dynalco and is to be returned to Dynalco upon request.	ANGULAR ± 1/2	06/20/07		NG NUMBER -12705		REV