

Type1GC External Photo (1)






Back side





Type1GC External Photo (2)




Certification target



Note)

RF connector is used only for inspection.



Module

Feed line

Antenna