ID Label Location & Sample

LABEL LOCATION: Label will be printed on the REAR of the product



LABEL Drawing

Transmitter type: NTP(Without Transponder)

MODEL: RK960NAT

(RM0-100001)

FCC ID: VQQ-RK960NAT

IC: 7313A-RK960NAT

Transmitter type: WTP(With Transponder)

MODEL: RK960NAT

(RM0-100008)

FCC ID: VQQ-RK960NAT

IC: 7313A-RK960NAT