
APPENDIX IV

Internal Photos


EUT – Uncovered View (PAR38A23)



EUT – Components View (PAR38A23)




EUT-Solder View (PAR38A23)




EUT – Uncovered View (PAR30A15)



EUT – Components View (PAR30A15)




EUT-Solder View (PAR30A15)




EUT – Uncovered View (R40A23)



EUT –Components View (R40A23)



EUT-Solder View (R40A23)



EUT – Uncovered View (R30A15)



EUT –Components View (R30A15)



EUT-Solder View (R30A15)

