# GE GE Bluetooth



**User Manual** 

# CiD Index

Quick-Start Guide3				
Pairing Guide 4				
Pairing Troubleshooting	. 4			
Operation	5			
Connection	5			
Connection Priority	. 5			
Dial	. 5			
Reject a Call	. 5			
Private Call	. 5			
Disconnect from Kit	. 5			
Volume Control	6			
Sound Quality	6			
Connection Diagram				
Specification 5				



# Specifications

# **Product Specifications**

,	,,		
Power supply voltage scope	DC 9 ~ 25 volts		
Working temperature	-25°C ~ 75°C		
Storage temperature	-35°C ~ 85°C		
Current consumption	In Operation:  • ACC ON (during charging + conversation)°800mA ~1.5A(Max) / DC 12V  In Static Mode:  • ACC ON (during charging)°~ 800mA(Max) / DC 12V  • ACC ON (mobile is not connected) °~ 180mA(Max) / DC 12V  • ACC OFF °~ 0mA		
Microphone (including amplifying circuit)	Category: FT105A Directional Sensitivity: 50dB ± 4dB tolerance SN ratio: >55dB (Min) Frequency response: 100 ~ 16 KHz		
Amplifier output (loudspeaker drive)	Output power: 5W RMS 35W (Max) Impedance: 4 Ohm Max output current: 2.6A Max undistorted amplitude: 8Vpp		
Mute Mode	LO_MUTE Operating Current: 50mA (Max)		
Bluetooth DSP	Full Duplex, Noise Reduction, Echo Cancellation		
Bluetooth module	Conform to Bluetooth Headset Profile v2.0, v1.1		
Transmission specification of each terminal	Terminal connecting to the vehicle bodyline > Batt: • Supply Voltage: 9 ~ 25 volts • Supply Currend: 3A (Max)		

CE F©



www.cigblue.com

CiG-Blue<sup>™</sup> Bluetooth In-Car Handsfree Systen



# Operation

Bluetooth

# CiD

## **Volume Control**

Volume up is adjusted by a short press on the button. The volume will be increased by one step per second. Once you have found the desired volume level you press the button once more to select. Volume down is adjusted by 2 short presses on the button. The volume will be decreased by one step per second. Once you have found the desired volume level you press the button once more to select. On each end of the scale you will hear a beep. This means you have reached the lowest or the highest volume level you must press once to stop adjusting.

# CiĐ

# **Sound Quality**


The system uses the highest quality components and latest full duplex DSP (digital signal processing) to give you the best possible sound quality for the caller and receiver. A few things must be remembered though to give you the best results.


- a. Road Noise The faster you drive the more background noise exists and the lower the sound quality will be for your caller. The system has excellent full duplex DSP to reduce the noise but closing your windows etc. will help.
- **b. Echo Cancellation** The system has excellent Echo cancellation to prevent the callers from hearing themselves back through the kit. To give the best quality for your caller try and have the volume at the lowest level which you can still easily hear them. This helps reduce any echo effects.
- **c. Full Duplex** The system has excellent Full Duplex system to make it possible for both callers to hear ech other talk simultaniusly. It can happen that older mobile phones don't support full duplex. We advice to keep this in mind when you purchase a mobile phone.
- **d. Talk at a normal level** Some older phone systems you had to yell at the system for people to hear you. This system uses the latest in sensitive microphones to allow you to talk at anormal level. If you yell at the system then your voice will be reduced in volume by the DSP and you may even sound quieter. Just talk at a normal level and your caller will easily be able to hear you.

**IMPORTANT** If you arrive at your destination during a call, it may be necessary to transfer the call back to your handset. Normally the call will be transfered back to your handset automatically when you turn of your vehicle, it can happen with older mobile phones that the call gets disconected. To avoid this fromhappening when you experience this, hold the CiG-Blue button for 4 seconds until you hear 2 beeps. (transfer to headset in page 3)



## **Connection Diagram**





CIG-Blue<sup>TM</sup> Bluetooth In-Car Handsfree System User Manual

CiĐ

# Quick-Start Guide

Bluetooth

## **Bluetooth In-Car Hands Free System**

Device ID	CiG-Blue_####			
Pass Key	1234			

Power On	Turn On Bluetooth		When the vehicle is turned on, the last used paired cell phone will automatically connect to the CiG-Blue system. If the phone has not been paired, the CiG-Blue will enter pairing mode for the next 5 minutes.
Pairing	Press and hold for 8 seconds	תת	Press and hold the button until you hear <b>3 beeps</b> , after 8 seconds. Using your phone to complete the pairing, enter the Pass Key "1234".
Answer a Call	Short button press		Just a short press of the button answers an incoming call.
Ending a Call	Hold for 2 seconds	<b>,</b>	To hang up, press and hold until you hear <b>1 beep</b> after 2 seconds.
Reject a Call	Hold for 2 seconds	<b>,</b>	To reject an incoming call press and hold the button until you hear <b>1</b> beep, after 2 seconds.
Adjust the volume	One short button pre to start volume up. Two short button pre to start volume down To stop Volume up/d press button once me	sses own	During a call, the volume can be adjusted. Press button once to adjust volume up or press button twice to adjust volume down. Now the volume will adjust in 1 step per second. Once you have found the desired volume level you press the button once more to select. A tone sounds when you reach each end of the scale in this case you press once to stop the volume adjustment. If this is not the volume level you desire press once or twice to adjust volume adjustment in opposite direction.
Transfer to the Handset	Hold for 4 seconds	<u></u>	Press and hold the button until you hear <b>2 beeps</b> after 8 seconds, to transfer the call between the CiG Blue hands free system and your handset.
Redial the last number	Hold for 2 seconds	<u>,</u>	In standby mode, press and hold the button until you hear <b>1 beep</b> after 2 seconds to redial the last number.
Voice Dialling	Short button press		In standby mode, a short tap of the button activates the voice dial feature

6



# Pairing Guide

Bluetooth

## Pairing your phone is simple, just follow these steps:

(The system can pair up to 10 phones)

- 1. Hold button down until you hear 3 short beeps, after 8 seconds (This puts the system into pairing mode for 5 minutes)
- 2. Go to settings or connections in your phone menu.
- 3. Find Bluetooth menu.
- 4. Turn Bluetooth on.

Your phone will have a function like:

Search for new device → New → Handsfree Search

Depending on the phone, the selection will vary, select the function and the phone will search for the bluetooth kit.

Your Phone will then display all the bluetooth devices in the area. Select CiG-Blue. Enter the passcode 1234. The system will let out a positive bleep to advise you are now paired.

**IMPORTANT NOKIA USERS** if you want the kit to connect automatically you must now select Paired Devices and select the CiG-Blue and change default to: **Device Authorised** → Yes, or **Conn Auth** → Yes or **Auto-Conn. Without Confirmation** — Yes This allows your phone to automatically connect when you start the car.

Once you reached the maximum of 10 paired phones the next pair(s) will automatically replace the oldest pair(s)

# **Pairing Troubleshooting**

	Can not find the Bluetooth menu	Please see the user manual of your phone for assistance on various phone models.		
	Phone will not pair	Sometimes phones have software problems and need to be reset.  Please remove and reinstall your battery and try again. Try deleting all other devices from your phone and try again, as you may have exceeded the maximum number of connections for your handset.		
	I paired my phone but when I start the car, it does not connect automatically	See The Pairing Note for Nokia users.		



# Operation

Bluetooth

## **Connection**

After you enter the car and turn the ignition on, the system will link with your phone automaticly. If it is the first time you have connected or your phone was not the last to connect you have to reconect using your connection menu in your mobille phone

(1 bluetooth menu, 2 handsfree/myhandsfree, 3 select CiG-Blue\_\_\*\*\*\*\*, press connect)

# Cia

- a. Voice Dial A quick press of the button activates the voice dial feature on your handset, and when ready the system lets out a "Bleep". Speak out the name of the person you wish to call. These names must be pre-recorded on the phone. Follow the instructions in your phone user manual on how to record the names. To cancel a voice dial press the button once more. If the phone has no voice dials or does not support voice dial you hear 4 negative beeps.
- b. Dial a number Enter the number you want to dial on the phone and press the dial button.
- c. Redial To redial a last called number, press and hold the button until you hear one beep after 2 seconds

# Reject a Call

Dial

Hold the button down until you hear a beep after 2 seconds to reject an incoming call.

# CiĐ

## **Private Call**

If you want to have a private call on your handset, after you answer the call simply press and hold the button until you hear 2 beeps after 4 seconds and the system will transfer the call to the handset. Press and hold the button again until you hear 2 beeps after 4 seconds to get the call back on the handsfree system.

## **Disconnect from Kit**

If you enter the car and you do not want any phone calls in hands free mode, just press and hold the button until you hear 2 beeps after 4 seconds and the kit will disconnect. When calls come in they will only be on your handset. To manually connect again, press and hold the button again until you hear 2 beeps after 4 seconds or restart the vehicle.

5

# Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCC grant.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help.

The equipment compliance with FCC radiation exposure limit set forth for uncontrolled Environment