

Control System

 ϵ

DD2702H Emitter Specification

Version NO.: A/o1







DD2702H Back If you need to change the battery, please push down the rear cover.





Technical support


DD2702H

support

Technical specification	Function instruction
• Input voltage: 3V (CR2450) • Transmitting frequency: 433.925MHz • Transmitting power: 10 Milliwatt • Operating temperature: -10°C ~ 50°C	DD2702H is 15-channel emitter. One number of LCD screen means one control channel. Press "channel choose" button P1- (number descending) or P1+ (number increasing) to change the channel. On the analogy of this, loose finger when the LCD screen shows the suitable channel that you select effective channel. If LCD screen number show "o" that means all channels if effective (group control state). When the group control status, you can not setting up, add emitter and other settings. When the voltage is below 2.6V, the LCD screen shows the battery icon, indicating the replacement of the battery.
	Notice: Emitter couldn't be exposed to moisture and striked, so as not to affect life.When you use emitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling. Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.







FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.