III. Installation:

- **1.** Make sure that your system is turned off and unplugged. Disconnect the AC power cord from your old power supply.
- **2.** Open your computer case, please refer to the direction in your case manual.
- **3.** Disconnect all power connectors from the devices
- **4.** Remove the old power supply and replace the new one into your computer case.
- **5.** Connect power connectors to your motherboard and peripheral devices.

Check to make sure that all cables and wires are securely connected

Connect the detachable 24/20pin Main Power Connector to your motherboard.

Connect the 4/8pin +12V Power Connector to your motherboard as needed.

Connect the peripheral 4pin Power Connector to devices.

SATA Connectors are for devices with serial ATA interface.

Connect the Y type Floppy Drive Power Adapter to the floppy as needed

Connect the PCI-E +12V Power Connector(s) to the PCI-E graphics cards.

If needed, please consult your graphics card manual for details

6. Close your computer case, connect the power cord to the power supply, and then set the "I/O" switch of the power supply to "I" position

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can r adiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause armful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation.