

WIRELESS - 20m Touchpad keyboard

Ideal keyboard for Home Theater PC Media Center

80mm multiple point finger gesture Touchpad






Premium Black / White Finish

- Microsoft Windows 2000/2003/XP/Vista Compatible
- Microsoft Vista Media Center shortcut key
- Ultra Slim body thickest section of 14mm Auto sleep of battery life over 3 months*
- Multi-Point touchpad with 7 operations
- 2.4Ghz Range up to 20 meters

Definition of Finger Gestures for multi-point touchpad:









Right click



finaer



Drag

Tap and drag




Vertical scroll

Slide 2 fingers vertically



Features Diagram:





(10) Volume Down button

(11) Premium Black / White Finish

(13) Large 80mm high sensitive touchpad

12) 2 mouse function keys similar to those on mouse

Extended feet for tilt to reduce fatigue with remarkably natural typing feel

- Microsoft Vista Media Center Shortcut
- (2) Windows Media Player Shortcut
- (3) Internet Browser Shortcut
- Outlook Express Shortcut
- (6) Play / Pause Button (7) Stop Button
- (8) Mute Button
- USB 2.0



Features:

Build a Home Theater, connect your PC to your large TV screen. Control your PC from up to 20 meters away with this wireless laptop-style keyboard with incorporated mouse! Perfect for Media Center use!

- Wireless slimline-keyboard with built-in touchpad
- Compatible: Win 2000 / 2003 / XP / Vista
- Laptop style full sized keys, save space with excellent comfort
- Multi-point finger gesture with 7 touch-sensitive operations
- Ultra Slim body with thickest section of only 14mm
 Enjoy total control of your PC of up to 20 meters from receiver in radius
- Power saving technology with auto sleep for efficient battery life to over 3 months*
 Subtle, Refined design to bring excellent comfort to users
- Ideal for Home Theater, VOIP, presentation and security systems facilities
- Full functionality of a standard layout keyboard including built-in numeric keypad
- Quiet keyboard & mouse buttons with tactile feedback
- Simple USB Plug & Play no driver & software required
- 10 shortcut keys for :
- Vista Media Center, Media Player, Email, Internet Browser & Audio Controls etc.

Technical Specifications:

Enhanced Controls:

- $80 mm \ multiple$ point finger gesture Touchpad with Left & Right mouse buttons.
- 88 keys top class scissors-switch keys with embeded numeric keypad
- 10 shourtcut keys for
 - Vista Media Center, Media Player, Email, Internet Browser & Audio Controls etc.

Powerful radio-frequency transmission of 2.4Ghz (Up to 20 meters)

Power and Batteries:

- Operation voltage 2.8V ~ 5.5V
- Operation temperature: 0° C ~ 60° C / Storage temperature: -40° C ~ 70° C
- Standard 4 x AAA 1.5V Alkaline batteries
- Power saving mode for efficient batteries life to over 3 months*
- Current consumption:
- Operation Mode <10mA, Standby Mode 170µA, Deep sleep Mode 10µA

- Keyboard dimension: 14mm (H) X 310mm (W) X 216 mm (D)
- Touchpad dimension: 65mm (W) X 49 mm (D)

Package Contents:

- WIRELESS Touchpad keyboard
- USB mini-receiver

Product design & developed by: ERC CONCEPTS (www.ercconcepts.co.uk)

- * Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help