

EUT Internal Photos

Figure 7

M/N: 880E, General Appearance (Removed USB Extend Seat)

Figure 8

M/N: 880E, USB Extend Seat, General Appearance

Figure 9
M/N: 880E, Internal View (Removed Battery Cover)



Figure 10
M/N: 880E, Internal View (Removed Cover)




Figure 11
M/N: 870E, Internal View (Removed Battery Cover)



Figure 12
M/N: 870E, Internal View (Removed Cover)



Figure 13
M/N: 880E, Internal View (Main Board, Front View)(with USB Port)




Figure 14
M/N: 870E, Internal View (Main Board, Front View)(without USB Port)




Figure 15
Internal View (Main Board, Back View)






Figure 16
RF IC View



*Figure 17
Internal View (Panel, Front View)*



*Figure 18
Internal View (Panel, Back View)*



Figure 19
Internal View (Switch Board, Front View)




Figure 20
Internal View (Switch Board, Back View)




Figure 21
M/N: 880E, Internal View (Main Board, Front View)(with USB Port)
(RemovedRF Module)




Figure 22
M/N: 870E, Internal View (Main Board, Front View)(without USB Port)
(RemovedRF Module)




Figure 23
Internal View (RF Module, Front View)




Figure 24
Internal View (RF Module, Back View)

