



Figure 7
Signal Port of the EUT



Inside Configuration of the EUT







Figure 10
Inside Configuration of the EUT












Figure 12
Backside of the LCD Panel





Figure 13 Label of the LCD Panel




Figure 14 Frontside of the Main Board





Figure 15Backside of the Main Board



Figure 16 Frontside of the Main Board






Figure 17Backside of the Main Board




Figure 18 Frontside of the Power Board







Figure 19Backside of the Power Board



Figure 20 Frontside of the Power Board






Figure 21 Frontside of the Power Board




Figure 22
Frontside of the PCB Board







Figure 23 Backside of the PCB Board





Figure 24
Frontside of the PCB Board










Figure 25Backside of the PCB Board





Figure 26
Frontside of the PCB Board













Figure 28 Backside of the PCB Board










Figure 29Backside of the PCB Board




Figure 30 Backside of the PCB Board






Figure 31Backside of the PCB Board



Figure 32 Speaker







Figure 33 Speaker



Figure 34
Remote







FCC ID: W8U55FS4610R



