Figure 9
Inside Configuration of the EUT

Figure 10
Inside Configuration of the EUT

Figure 11
Inside Configuration of the EUT

Figure 12
Inside Configuration of the EUT

Figure 13
Frontside of the LCD Panel

Figure 14
Backside of the LCD Panel

Figure 15
Label of the LCD Panel

**Figure 16**
Frontside of the Main Board

**Figure 17**
Backside of the Main Board

Figure 18
Frontside of the Main Board

Figure 19
Backside of the Main Board


Figure 20
Frontside of the PCB Board

Figure 21
Backside of the PCB Board

Figure 22
Frontside of the Power Board

Figure 23
Backside of the Power Board

**Figure 24**
Frontside of the Power Board

Figure 25
Frontside of the Power Board

**Figure 26**
Frontside of the PCB Board

Figure 27
Backside of the PCB Board

Figure 28
Frontside of the PCB Board

Figure 29
Backside of the PCB Board

Figure 30
TV Tuner

07-500WF3-SA0G
DT21WN-6-E
1311022835 03 0P B