



Figure 7
General Appearance of the EUT



Figure 8Inside Configuration of the EUT





Figure 9 Inside Configuration of the EUT



Figure 10 Inside Configuration of the EUT







Figure 11
Frontside of the LCD Panel



Figure 12 Backside of the LCD Panel





Figure 13
Label of the LCD Panel



LVW320NEAL SJHW00 V1 08-32E5310-LPN001A

Figure 14 Frontside of the Main Board






Figure 15
Backside of the Main Board




Figure 16 Frontside of the Main Board







Figure 17
Backside of the Main Board



Frontside of the Power Board







Figure 19
Backside of the Power Board



Frontside of the Power Board







Figure 21
Backside of the Power Board



Frontside of the Power Board







Figure 23
Backside of the Power Board



Frontside of the PCB Board









Figure 25
Backside of the PCB Board




Frontside of the PCB Board







Figure 27
Backside of the PCB Board



Frontside of the PCB Board








Figure 29
Backside of the PCB Board




Figure 30 ANT of the Board





Figure 31
Speaker



Figure 32 Speaker

