

FIGURE 2 LCD TV (M/N: LEDN19K15US) LCD PANEL LABEL






FIGURE 4
LCD TV (M/N: LEDN19K15US)
DC POWER BOARD (SOLDERED SIDE)






FIGURE 6
LCD TV (M/N: LEDN19K15US)
MAIN BOARD (SOLDERED SIDE)



FIGURE 7
LCD TV (M/N: LEDN19K15US)
CHIP & CRYSTAL ON MAIN BOARD



FIGURE 8 LCD TV (M/N: LEDN19K15US) TUNER







FIGURE 10 LCD TV (M/N: LEDN19K15US) KEY BOARD (SOLDERED SIDE)







FIGURE 12 LCD TV (M/N: LEDN19K15US) LCD PANEL BOARD (SOLDERED SIDE)






FIGURE 14 LCD TV (M/N: LEDN19K15US) KEY BOARD (SOLDERED SIDE)






FIGURE 16 LCD TV (M/N: LEDN19K15US) ADAPTOR (GENERAL APPEARANCE – BACK VIEW)



FIGURE 17 LCD TV (M/N: LEDN19K15US) ADAPTOR (PORT)



FIGURE 18 LCD TV (M/N: LEDN19K15US) ADAPTOR (LABEL)



FIGURE 19 LCD TV (M/N: LEDN19K15US) ADAPTOR (COVER REMOVED)





FIGURE 21 LCD TV (M/N: LEDN19K15US) ADAPTOR (MAIN BOARD – SOLDERED SIDE)



