# Test Setup photographs

EUT Position: X-axis

EUT Position: Y-axis

EUT Position: Z-axis

Test Setup Photo of Radiated Measurement (ERP)

Test Setup Photo of Radiated Measurement (EIRP)