




HEADPHONE



HEADPHONE




RECEIVER





Class AB Speaker


If use combined speaker and receiver ,then Analog switch are needed to prevent reverse current.Pls refer to <<SC6600H Speaker&Receiver Application Notes>>




SC6610_PLATFORM_REFERENCE_SCH_V1.0.0.sch HW-SC6610-SCH-2011-0001 Hardware RD. 2011-02-14 Franks.Miao 2011-02-14 Robin.Zhang Spreadtrum communications, Inc. Guobing.Luan 2011-02-14 CONFIDENTIAL AND PROPRIETARY SHEET: 6 OF 16









KEYPAD Press this button when power up will make the phone boot from USB KEYOUT0 ONKEY high active [1,9] pencil DEL [1,9] [1,9] [1,9] [1,9] down2KEYIN5 [1,9] CANCEL RIGHT [1,9] CALL2 SC6610_PLATFORM_REFERENCE_SCH_V1.0.0.sch HW-SC6610-SCH-2011-0001 Hardware RD. 2011-02-14 Franks.Miao 2011-02-14 Robin.Zhang Spreadtrum communications, Inc.

Guobing.Luan

2011-02-14

SHEET: 11 OF 16

