



CLOUD FOX

Cloud Fox Technology Co., Ltd.
Email: support@icloudfox.com
Website: www.icloudfox.com
Tel: +1(833) 275 3677
Made in Shenzhen, China

Bluetooth Connection
1. With the headphone power OFF, Hold Bluetooth button depressed for three seconds and hear Power on, the blue LED indicator flashing three times, then enter the pairing mode(the LED indicator's flashing blue and red)
2. When in the pairing mode, if pairing is not completed within about five minutes, the power will automatically turn off.
3. Turn on the power to the Bluetooth device you wish to pair with, and begin pairing; search for this unit from the paired Bluetooth device.
Set the Bluetooth device within one meter to the wireless headphones.
These wireless headphones will appear in the Bluetooth device's display as "CLOUD FOX H7".
4. Confirm that pairing has been successfully completed with the Bluetooth device. Look at the display for the Bluetooth-enabled device and select "CLOUD FOX H7".
5. Pairing is confirmed when the LED indicator flashes blue at the intervals of three seconds.

1. When the headphone already paired with a device, it will alternately connect when both devices powered on and stay within 1m. If you want to pair with another device, please disconnect the previous device first.
2. If the pairing is not successful, please switch off headset firstly and then re-pair again.

Function guidance

Button	Operation	Function
+	Long Press	Next song
	Short Press	Volume up
-	Long Press	Previous Song
	Short Press	Volume down
Bluetooth	Short Press	Play/Pause/Answering calling/Reject calling
	Long Press	Pairing mode
ANC	slide the ANC button to another side	ANC Mode

Battery Charging
The device can be powered by a built-in rechargeable lithium battery. Please charge the battery for at least 8 hours before your first use of device. The accessory micro-USB cable must be used for recharging the unit's battery. Connect the appropriate connector on the accessory micro-USB cable to the micro-USB port on the headphones, and the USB plug on the other end to a USB port on a computer. When recharging begins, the LED indicator on the headphones will light red. Full recharging requires about three hours; when recharging is completed, the LED indicator will turn off. When the battery's charge is approaching depletion, a beep sound will be heard in the headphones at one-minute intervals.

Troubleshooting

Problem	Remedy
Power won't turn on	Recharge the wireless headphones Confirm that computer is connected Confirm that computer is not in power-saving mode
The batteries will not charge	Confirm that accessory micro-USB cable is securely connected to both the wireless headphones and computer
Can't perform pairing	Place the wireless headphones and Bluetooth device closely together when performing pairing

FCC Statement:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved by the party responsible could void the user's authority to operate the equipment.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.