





INSTRUCTIONS

- It will take 6-7 hours to fully charge the battery under 10V voltage.
- Install the fully charged battery into the chassis battery box, connect the circuit and screw the cover
- Pls install the battery into the controller, open the lid and insert the 9v battery according to its polarity shown below, then close the lid.
- Push the switch to the "ON" position on both the car and the controller, and the instruction light will turn on.
- Adjust the direction adjustment switch to control the car running in a beeline

CAUTION

- CAUTION

 1. Please change the batteries with new ones once they are exhausted.

 2. Do not mix new and old batteries together.

 3. Please remove batteries if the car will not be used for a longer period of time.

 4. Do not over charge the battery.

 5. The battery should be kept fully charged and should be recharged every month if not used for a longer period of time. This helps prevent the circuit board from becoming additied

 6. The battery should never be put near fire or any source of heat,nor should it be thrown into fire or left in direct sunlight.

 7. The battery should he changed if the hattery is broken or if the battery is leaking.

- in direct sunlight.

 7. The battery should be changed if the battery is broken or if the battery is leaking.

 8. Skin and clothing should be washed immediately if they come in contact with the liquid from the battery

 9. Exhausted batteries are to be removed from the toy.

 10. Non-rechangeable batteries are not to be recharged.

 11. Rechargeable batteries are to be removed from the toy before charged.

 12. Rechargeable batteries are only to be charged under adult supervision.

 13. The rechargeable battery power connector should be matched with charger's and Car's.

Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

NOILE
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio comunications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or televion reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- □ Reorient or relocate the receiving antenna.
 □ Increase the separation between the equipment and receiver.
 □ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 □ Consult the dealer or an experienced radio/TV technician for help.




The rechargeable battery must be charged for 12 hours before first using. After its first use, the battery only needs to be charged for 6-7 hours for maximum











FEATURES & FUNCTIONS:

Scale: 1:14 Functions: Forward, Reverse, Turn Left, Turn Right ,Stop

and Front lights.
Features:Authentic car styling with injection moulded body, Independent suspension syste







Ford Oval and nameplates are registered trademarks owned and licensed by Ford Motor Company. Http://www.ford.com

Manufactured by XINGHUI PLASTIC INDUSTRY CO., LTD.

