
Bluetooth

GP3 Thump 2

USER GUIDE





Charging Your Headset

The Headset comes with a built-in rechargeable battery. Prior to using the headset, it is recommended to charge the battery fully for the first time.



Fig.1 Fig.2

Charging Your Headset

Connect the charger to an AC wall outlet (mains socket) and the charger plug to the headset's USB socket. The red LED will flash. Or you can charge your headset when it is connected to your

IMPORTANT Charging indication will be delayed for a few seconds if the headset has not been used for a long time or the battery is drained.

Charging Time

The battery can be fully charged normally within 2 hours. Then you can disconnect the charger from AC wall outlet (mains socket).



Turn On/Off

Turn on/off the MP3 function.

Press and hold Key A for 2 seconds until the red LED is on, now the MP3 function is turned on and at Pause state. Short press Key A then to play songs and short press it again for Pause

Press and hold Key A for 3 seconds until the red LED quickly flashes for 3 times, now the MP3 function is turned off.

Note: if the pause time lasts over 30 seconds not being interrupted by Bluetooth, MP3 function will automatically turn off. (LED: MP3 Playing ---- Red flash slowly

MP3 Pause ---- Red on

Mp3 Data transferring ---- Red flash quickly)

2. Turn on/off the Bluetooth function.

Press and hold Key E for 5 seconds until the blue LED is on, now the Bluetooth functions is turned on and you can pair the headset with Bluetooth-enabled mobile phones.

Press and hold Key E for 3 seconds until the blue LED quickly flashes for 3 times, now the Bluetooth function is turned off.

Note: for turning on, if you press and hold key E for only 2 seconds and blue LED flashes slowly, it means Bluetooth is under Stand state; you have to turn off Bluetooth at first and turn it on as above for pairing. (LED: Bluetooth Pairing ---- Blue on

Bluetooth Stand ---- Blue flash slowly Bluetooth Working ---- Blue flash quickly)

Keys at MP3 / Bluetooth state

1.At MP3 state

Key B

Short press, it will turn to the next song; press and hold, the volume will increase

Key C

Short press, it will turn to the last song; press and hold, the volume will decrease.

2. At Bluetooth state. For Bluetooth MP3. 1)

Key B and Key C

The same as at MP3 state.

B. Key D.

Short press, Bluetooth MP3 will pause.

Press and hold, re-dial the last number you dialed out.

For Bluetooth Call.

A. Key B and Key C

Press and hold Key B, the volume will increase; press and hold Key C, the volume will decrease.

Key D

Short press, you can receive the call; short press again for finishing the call;

Press and hold, you can reject the coming call.

Between Mp3 function and Bluetooth function

1. Bluetooth function always takes precedence of MP3 function;

2.When you turn on Bluetooth MP3 or Bluetooth Call, MP3 function will automatically be paused, and automatically play again after Bluetooth function stops.

 Note: Mp3 function won't be turned off automatically until you press its Pause or Off key.

Pairing Your Headset

The headset only works with Bluetooth-enabled mobile phones. Prior to using and pairing your headset for the first time, please check if your mobile phone is Bluetooth-enabled. The headset pairing procedure may vary depending on the model of your mobile phone. Please contact the manufacturer of your mobile phone or its agent for further information.

Place the headset and the mobile handset no more than

10 meters apart and ensure there is nothing in between;

Press and hold Key E for 5 seconds until the blue LED is on, now the Bluetooth functions is turned on;

 Active your mobile handset's Bluetooth function by referring to your mobile handset user guide for details;

 Set the mobile handset to search for Bluetooth devices within 10 meters range as instructed in the mobile handset user guide, and select "thump 2" from the list;

4

Enter the preprogrammed passkey '0000' and press OK to pair your headset and mobile handset;

After pairing completed, the Bluetooth will be at Stand state and its blue LED will flash slowly.

Download the music to your headset

Connect your headset to your computer with the USB cable, at the same time, the red LED will flash quickly during the downloading.

Care and Maintenance Headset

 Make sure you turn the headset off before placing it in your pocket or bag.

Do not expose the headset to liquid, moisture or humidity as it is not waterproof.

3.Do not use abrasive cleaning solvents to clean the headset.

4.Do not expose the headset to extremely high or low temperatures

5.Do not dispose the headset in a fire as it will result in explosion.
6.Do not expose your headset with sharp objects as this will cause scratches and damage.

7.Do not stick anything inside the headset as this may damage internal components.

8.Do not attempt to disassemble the headset as it does not contain service range.

 If you do not use the headset for long periods, be sure to store it in a dry place, free from extreme temperature and dust.

Built-in Battery

 Do not attempt to replace the headset's battery yourself as it is built into the headset and is not changeable.

Charge the battery in accordance with the instruction supplied within this user guide.

Only use the charger supplied by manufacturer when charging the headset.

Charger

 Only use the charger supplied by manufacturer when charging the headset.

2.Do not disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.

3.Do not use the charger outdoors or in damp areas.

 Only charge the headset's built-in battery in accordance with the instructions in this user guide.

Avoid charging the headset in extremely high or low temperatures.

Safety Information

1.Check local laws regarding use of a mobile handset and headset whilst driving. If you use the headset while driving, ensure your attention and focus remain on the road and you drive in a responsible and safe manner.

Never allow children play with the headset small parts, it may

be a choking hazard.

 Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive environments.

 Turn off your headset before boarding an aircraft. Do not use your headset in an aircraft.

 Never mount or store your headset over any air bag deployment area as serious injury may result when an air bag deploys.

6. Do not open or mutilate the built-in battery.

Dispose batteries according to local regulations. Do not dispose as household waste.

Dispose the packaging and this product in accordance with the latest provisions.

(6

Troubleshooting

 If you are unable to connect your headset with your mobile handset or Bluetooth enabled device, please try the following:

①Ensure your headset is turned on and is properly charged. ②Ensure the headset is paired with your mobile handset.

Sensure your mobile handset's Bluetooth feature is activated.

Please refer to your mobile handset user guide for specific instruction.

④ Ensure the headset is within a maximum of 10 meters of your mobile handset(s) and there are no obstructions, such as walls or other electronic devices in between.

If the above suggestions do not solve your problem, please recharge the headset and remove your mobile phone battery for a while. Then start pairing again.

Product Specifications:

Bluetooth Specification:	1.2
Range of Frequency:	2.4GHz spectrum
Talk Time:	1 hour
Music Playing Time: Standby Time:	3 hours 72 hours
Nominal Charging Time:	2 hours (80% charged in 1 hour)
SNR(db):	85
Memory:	512MB/1G/2G/4G
THD:	<0.1%
Max input power rating:	5VDC/150mA
Codec supported:	MP3/WMA

*May vary due to users' operation mode and mobile phone settings

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.