Operational Description(FM1000series)

- 1. FACU(Fingerprint Access Control Unit) has to be set by administration number of device after connected adaptor power (12V, 2.5A).
- 2. Input the administration number and do user registration per individuals (There are three types of registration, Fingerprint, RF Card and Pin#)
- 3. The ways of access for the registered users.
- 3-1. In case of access by fingerprint, press "#ENT" button on Keypad and touch the registered finger on the part of fingerprint authentication, then it's able to do access with audio voice and displaying "You can pass" on LCD screen.
- 3-2. In case of access by RF card, proximate card on the displayed part as "RF CARD", then it's able to do access with audio voice and displaying "You can pass" on LCD screen.
- 3-3. In case of access by Pin#, after input user's ID number and Pin# on the part of user's Pin#, press "F4" on Keypad, then it's able to do access with audio voice and displaying "allowed access" on LCD screen.
- 3-4. In case two or three types of access configuration concurrently among 3 types as above, it's the same methods of access can be applied.
 - * In case of the unregistered users are forced to recognize by using fingerprint, RF card and Pin#, it shows error message as "Please contact Security Manager" on LCD screen with voice.
- 4. The applicable usage of these products can be installed and used at public & official wards, private company, research institutes, military base, and financial institutes.
 - * Refer to user's manual if you have any further details on usage.

End.