Rearview Mirror Multimedia With GPS and Blue-tooth

User's Manual

Please read this manual carefully before use this product



Welcome to choose our product

-----Rearview Mirror multimedia with GPS and blue-tooth!

- 1. The User Manual, all rights reserved to our company.
- 2. Please copy the important data, our company will not take care for it in case any lost.
- Pictures in the manual for reference only, please execute with the actual object in hand!

Caution:

- Three reasons caused if the GPS can't connect with the satellite signal.
 - a): Please check if built-in navigation antenna works well.
 - b): It's normal to take a while to update the new information, and meanwhile the screen display in blank, take it easy, one moment, signal will come back.
 - C): Please check if the vehicle is running under the bridge, inside the channel or among the big buildings? Which those area will affect the signal reception.
- 2) Driver should not operate this navigation during the driving, in case of any security problem caused by!!
- Products will be continued updating, the final operation steps may has little changes comparing with this manual, please execute with the actual object in hand.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Notes:

The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

CE Caution:

Hereby, DSUS TECHNOLOGY INTERNATIONAL (HK) LIMITED, declares that this Rearview Mirror Multimedia With GPS and Bluetooth (Intended use/Category: Wideb and Data Transmission systems) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



	Language	Support Simple and complicate C language need to be updated.	hinese and English, other
	Picture Browser	Support JPG/GIF/BMP AND PNG	
	Multi-media Program	Have multi-media function but can same time	't use all the function at the
Unit	Button form	Power on/off	Will appear on the unit.
Appearance		Main Menu	surface
		Blue-tooth hands free receiving	
		Blue-tooth hands free hand up	
		Blue-tooth Pairing	
Power input		DC12V	•
Power Consumption		(5W	
Temperature		Working temperature: 0C-60C; Store -20C-460C	age temperature:

Contents

1. Product Appearance

2. User Knowledge:

- 2.1. How to shut on and off
- 2.2. Function of Indication Lights
- 2.3. Start-up Instruction
- 2.4. GPS Antenna Instruction
- 2.5. Touch Screen Cautions
- 2.6. Using Environment Cautions

3. Operation Instruction

- 3.1. Intelligent GPS
- 3.2. Multi-media function
- 3.3 Blue-tooth function
- 3.4. System Set-up

4. Specification Form

1. Product Appearance





	0.4 1	••
1	Power on/off	Turnon /turnoff
2	Returns to menu	Returns to mem
3	Handsfree Receiving	Execute blue-tooth hands freereceiving function
4	Handsfree Hang-up	Execute blue-tooth hands free hand-up function
5	Blue-tooth Pairing	Execute blue-tooth hands free pairing function
б	Touch - Pen	Click and write on the screen,
7	SD cardport	hichidinga S/D mem crycardwithmap software
8	GPS Receiver	Openthe GPS receiver to horizontal position to receive the satellite signal.
9	Bracket Installation	Install the bracket which is suitable to original auto structure
10	The Imputs	Power Port and Signal- input port
11	Microphone input	Link to microphone

2. User Know ledge

2.1. How to shut on and off

Press Power on/off Button in 1 second, the unit will operate automatically, and use the same way to sluit off the unit.

2.2. Function of Indication Lights

- A) The buttons on the surface will be lighted on when operating the unit.
- B) Pairing indication button is twinkling while pairing the blue-tooth and it will keep lighting if pairing successfully.

2.3. Start-up Instruction

During the start-up procedures, all the buttons don't work except the Power on/off Button, and it finished when the screen display the main menu.

2.4. GPS Antenna Instruction

This unit can receive the GPS signal well which is coming from the outer space satellite, although these GPS signals sometimes are very weak. But it doesn't mean in any environment, any location can be received well. User should open the antenna to face the sky, and operate this unitunder the area without the big building and barrier surrounding.

P.S. To avoid the receiving effective, DO NOT stick or put anything upon the antenna!

2.5. Touch Screen Cautions

Touching screen is made by special electric-resistance material, is very sensitive to the temperature, lumidity, pressure.etc. Therefore, In order to keep the touch screen

Specifications Form

Item		Specifications	Remarks
Operate system		Window CE Net4.2	E.g.:: window CE, NET4.X or pocket PC
CPU	Factory and model No	Samsung S3C244OA-400MHZ	0.000
RAM	Total RAM Capability	64MB	Suggest the smallest memory card
	Valid RAM Capability	64MB	capability should be 64MB but can use the 32MB as well
Memory Card	Support or Not	Yes	Support to enlarge the memory card or not
	Туре	SD/MMC	B.g.: SD card/ MMC card
	Capacities Range	256M/512M/1G/2G	Suggest the smallest memory card capability should be 256MB
	Route Name	SD MMC/Mobile Navigator/ Mobile Navigator.exe	Navigation route e g: memory card or SD card
LCD/monitor	inch/resolution	4 inch/480*272	
	Tint	16Bbit	1
Touch Screen	Related agreement	4-line electronic-resistance touch	Standard agreement
Voice	Speaker	Built-in 8 ohm/1 W Hi-Fi. londspeaker	Support speaker output
GPS	GPS input	Built-in open-up antenns	Blue-tooth card/inline and input
	GPS port	COMI	GPS get the data through COM1
	GPS Module	Switzerland-UBLOX -LEA4S or Samsung-sirf III	Receiving module No.
	Band rate	9600	e.g.: 4800/9600
Blue-tooth	Hands free calling	Support Hans free calling, dishing and called recording	
Video	Back Car video	Support switch to back car video automatically	
About OS	Audio Player	Support WMA9, MP3 upto 320kbps a	nd WAV
	Video Player	Support WMA9, Divx 5.0,4.0,3.11,Xvid and MPEG2 upto 320*240, WMA, asf, avi format	

D) Date and Time Setup

Date and time setup including below:

1)Date sets up system

Click Date Setup system and click "Date Button" to enter to adjust the date, you can press 🙉 or 🙉 to adjust the year, month and date. See picture below :

2) Time sets up system

Click Time Setup system and click "Time Button" to enter to adjust the time you can press on or to adjust the hour, minute and second. See picture below:





3-24 Date set

3-23 Date Time

E)Language

Language setup include below:

1 % ys tem indication language selection

Click language and press or a to choose the language, you can choose simple Chinese. complicate Chinese and English in the system

2)S ystem appearance selection

Click appearance and press on or to choose the appearance, you can choose yellow and blue in the system.



3-26 Language set



3-27 System Info

FK vs tem information

1)Return manufacture setup

Click "Manufacture" Button to enter "anufacture setup" menu Click " to return manufacture setup, and double click to close

the mem. See as 3-28

2) Return GPS mamufacture setup

Click "GPS Manufacture Setup" Button to enter "PS manufacture setup" menu Click " to return GPS manufacture setup, and double click to

close the menu. See as 3-29

3) Touch screen Adjusting

Click "Touch Screen Adjusting" Button to enter "touch screen adjusting" button mem, see as 3-30

Use the touch-pen to click the across touch center, from center, left up, left down, right up and right down to adjust the touch screen until it can orient successfully. S ys tem will close the Touch Screen Adjusting menu automatically and come back to the main mem







3-29 GPS Reset

3-30 Calibration

in a good working state, user should pay much attention to confirm it not to operate either under the temperature higher than 60 degree C or lower than 10 degree C. or the sunshine.

DO NOT scratch the screen surface with a sharp thing;

DO NOT click the screen surface with fingernail, should use the touch-pen;

DO NOT somb unit housing or the screen surface with water or organic solvent. Buy special-purpose cleaning spread to clean the screen surface. Please use the adjusting function inside the system while the touch screen is malfunction in case it is fail to adjust, contact your supplier immediately, DONOT open the unit by yourself.

2.6. Environment Cautions

A) Avoid to operate this unit underbelow environment: temperature change quickly, high temperature (above 60 degree), low temperature (0 degree of the following), high pressure, much dust, static interference, moistness, or be immersed in any liquid.

B) A void the radiation interference, or radiation from other electronic equipment. All those would affect the GPS function, remove those radiation, the GPS will display as normal.

3. Operation Instruction


1	Intelligent GPS	Detail pictures and the nationwide GPS for road
2	The medium broadcasting	Audio, vide o, photograph browsing, e-books
3	B hie -tooth call	Blue-toothhands free call, andtouch dialing
4	System setup	Volume, power, background lights, date and time, language and system information
5	Rearview Function	Automatically switch to rearview function under the backward state if the vehicle has the camera system.



3-1 Mem

3.1 Intelligent GPS

A)This unit receives the signal from satellite with the GPS signal receiver to search the destination actually and display on the map. Usually the system will calculate the best solution automatically after the user setup the destination, which this can help you find the road fast and safe. In order to give you



3-2 GPS receive environment

a easy and pleasure tour, the system will let you share our navigation system individual charm with e-map, flash, indicating speech and words etc

B)About the e-map

The unit uses the latest update e-map for navigation, but please drive according the actual routine under the Transportation Rules and Regulations, as the road will be changed after you got this unit for a while due to the Transportation Department would re-structure the route. Under this situation, please decide which way you should choose and refer the displaying map ONLY. Driver can choose a more effective routine than this GPS if you know the road well around.

or you can drive according the GPS indication or refer our navigation manual written by our company.

C) About receiving signal

GPS signal receiving will be affected by big and concentrated building (e.g.: tunnel, among huge building, underground parking and high bridge) or weather changing or the satellite signal closing, which will cause GPS can't orient or can't do it correctly then finally will be malfunction and the system will be disfunction. The tolerance of GPS orientations vs tem usually is Smeters. It will also have some tolerance while driving under the two parallel roads, the actual position maybe has some difference from the e-map, and even sometimes e-map will display on the nearest parallel road.

3.2. Multi-media function


Here introduce the multi-media function as below:

- A) Audio Player B) Picture Browser
- C) E-book
- D) Video Player

A) Audio Player

- a) The features of audio player
- 1) Support WMA9/MP3/WMA audio format. you can change the order as your want.
- 3-3 Multi-media mem
- 2) Please copy your audio documents to the memory card before you use it.
- B) Audio Player Operation Instruction

Click multimedia menu and choose Audio Player Button 2 see as 3-4



A) Volume Setup

Volume setup including below:

- 1) Speaker volume adjusting
- 2) The Clicking Volume on the screen



3-21 Volume set

×	Shut off	Click and exit volume adjusting	
0	Volume -	System has 10 classes volume, you click "-" one time, then the volume decrease 1 class	
•	Volume + System has 10 classes volume, you click "+" one time, then the volume increase 1 class		
0	Clicking Volume	Click and open clicking volume, double click then close	
	Current Volume	RED indicate the current volume, every grillemeans 1 class	

B) Powersetup

The main function for power setup is to display the power state and this unit can connect with the alternating current.

C) Backlights

Backlights setup including below:

1)Brightness adjusted

3-22 Back Light set

2) Setup the time gap under battery power supply. Setup the time gap under alternating current power supply.

×	Shut off	Click and exit the backlights setup program	
0	Brightness-	Click "-" to dark the backlights until the lowest point	
•	Brightness+	Click "+" to bright the back lights until the highest point	
(3)	Move left	Click " Time Gap Cohumn" to move left then display the previous contenand continuous displaying	
(3)	Move right	Click "Time Gap Column" to move right then display the next content, and continuous displaying	
THE REAL PROPERTY.	Brightness	RED indicate the current brightness	
	Time Gap	The backlights will slut off automatically after operating for a while and save the power. Then you will see the continuous displaying "Never", 3 m inutes, 2 minutes, 1 minutes, 30 seconds and 10 secondstotal 6 se lection	









3-14 Phone Keypad

3-15 Calling out

3-16 Incoming Call

B)Called Record

Called record is including dial out record, received record and missed call record. All those can dial out or delete directly.

C) Pairing

Pairing means that the blue-tooth system between this unit and the mobile can be connected, and the password for pairing is: SSSS

D)Pairing Record Information

Pairing Record Information means the pairing history record that the unit or the mobile did before, then can pair and delete faster.







3-17 Call Record

3-19 Pair de vices

3.4. System Set-up

Click the main menu and choose "Set-up Button" to entersystem set-up menu. You can reset the system here, including: Volume, Power, Backlights, Date and Time, Language and System Information.



3-20 System mem

Volume	To adjust the speaker volume, and clicking volume on the screen.	
Power	Check if the power works well.	
Backlights	To adjust the brightness of the backlights. Shut off the time gap of the backlights under the battery or alternating current power supply.	
Date and time	Time, date and time zone set-up	
Language	System indication language and appearance selection	
System Information Return the manufacture setup, including GPS Manufacture setup and Touch Screen Adjusting		



18	Shut off	Click and close the folder
(8)	Previous page	Show the content of previous page
(8)	Next page	Show the content of next page
0	Return	Com e back to last folder
∲ \MP3	Foldernam e	Show the displaying audio folder name
	Songrame/Format	Songname and its audio format







3-4 Audio player

3-5 Audio folder

3-6 Picture browser

B) Picture Browser

- a) The features of the picture browser
- 1) Support JPG/GIF/BMP/PNG format
- 2) Support the picture for rotating, enlarging/downsizing and displaying automatically.
- 3) Please copy your picture documents to the memory card before you use it.
- b) Picture Browser Operation Instruction

Click multimedia menu and choose "Picture Browser Button" , see as 3-6



×	Shut off	Click and close the picture browser
0	Enlarging	To enlarge the size comparing the displaying picture
9	Downsizing	To do wassize the size comparing the displaying picture
0	Rotating Picture	Click the current pictures and clockwise in 90 degree
6	Displaying automatically	Click and will continuous display the pictures
0	Previous picture	Browse previous picture in the same folder
0	Next pic ture	Browse next picture in the sun efolder
0	Folder	C lick and come back to the picture folder, choose the your favorate picture, see as 3-7
The same of	Foldername/Format	Display current displaying picture name and its format





c) Picture folder

	Shut off	C lick and close the folder
0	Previous page	Show the content of previous page
8	Next page	Show the content of next page
0	Return	Com e back to last folder
mg.	Folder nam e	Show the displaying picture folder wan e
P	Picture name/Form at	Picture name and its form at



3-7 Picture folder

C) E-book

- a) The feature of E-book
 - 1) Support TXT format version
 - 2) Support to turn the page and page selection or folder selection.
 - 3) Please copy your e-book documents (TXT format) to the memory card before you use it.



3-SE-book

b) E-book Operation Instruction

Click multimedia mem and choose "E-book Button" , see as 3-8



×	Shut off	Click and close the E-book
(2)	Previous page	Click andreadprevious page
•	Next page	Click andreadnext page
0	Scanpage	Click and display "Page Selection" see as 3-9, can select any page you want to read.
0	Folder	Click and come back the folder to choose the book you want to read
-	Foldername/format	Display current textfolder rome e and its format
DATE	Page No/Total page	Current page number and total page quantities

×	Shut off	Click and exit the page selection
	Numberkeyboard	Am ong 0-9, can constitute any figure from 0 to 9999.
0	Figure Displaying area	Displaying the figures you enter
0	Backspace	Press and delete the latest figure
0	Zero clearing	To clean all the figures
0	Return	Enter the page No, click and come back to that page




×	Shut off	C lick and close the folder
8	Previous page	Show the previous page
8	Next page	Show the next page
0	Return	Click and Come back to last folder
BOOK!	Folder røm e	Display the current book folder name
24	Book name/Form at	Book name and its form at

3-10 E-book folder

D) Video Player

- a) The features of vide o player
- 1) Support WMA/AS F/AVI format
- 2) Support full screen displaying, schedule and documents selection





3-11 Video player

b) Video Player Operation Instruction

Click multimedia menu and choose "Video Player Button"

(3)				
*	,	S	ee	as

s 3-11

×	Shut off	Click and Shut off Audio player	
0	Play	If the m ovie pause/stop, click and Continue to play	
0	Panse	If the movie is playing, press to pause the music	
0	Stop	If the movie is playing, press to stop the music	
•	Skip Forward	Click, the m ovie will skip forward; cance l, the m ovie will continuous to display.	
41	Volume	Pull the Adjusting Button on the volume left and right by touch pen, pull left for minus and pull right for plus.	
-	Schedule	Pull the Adjusting Button on the schedule left and right by touch pen, pull left for backward and pull right for forward and continuous to display	
0-0	Folder	Click and come back to the audiofolder, choose the your favorat movie, see as 3-12	
1100001010	Movie Name/Form at	Display the playing in ovie name and its form at	
10.50 / W. 40	Time	Show how long of the movie is playing and the total time	

	×	Shurt off	Click and close the folder	
Ī	8	Previous page	Show the content of previous page	
	8	Next page	Show the content of next page	
	0	Return	Com e back to last folder	
Ī	影声へ	Foldername	Display the currentmovie folder name	
Ī	22	Movie man e/Form at	Movie name andits form at	



3-12 Videoplayer folder

3.3. Blue-tooth

Click the main me m and choose "Blue-Tooth Button" , to enter blue-tooth mem. You can operate the blue-tooth function here, including Telephone Keyboard, Called Record,



3-13 Blue-tooth

Latest Call, Pairing, Blue-tooth Set-up, and Pairing Information.

A)Telephone Keyboard

Telephone keyboard is including all Arabic numbers and *, #, backspace, call and called record buttons.